


SIUS Bilaga till driftsinstruktion för System 7



Im Langhag 1
CH-8307 Effretikon

+41 (52) 354 60 60
Fax: +41 (52) 354 60 66
www.sius.com
admin@sius.com

SIUS AG

BASYS7AH1SR1

Menu.mpp - 03.07.2019

SIUS

Innehåll

Svenska

Sida

Figurer

10m

ISSF

Rörligt mål

Skidskytte

Övrigt

Divisions

Italy

25m

ISSF

Schweiz

Russia

50m

ISSF

Schweiz

Gevär

Finkaliber

Grovkaliber

Skidskytte

Divisions

Rörligt mål

FRA

300m

ISSF

CISM

Schweiz

A

2

2

2

3

3

4

4

4

5

5

5

6

6

6

7

7

8

9

10

11

11

11

12

12

12

12

12

SIUS

Innehåll

	Svenska
	<small>Sida</small>
B	13
Skandinavien	14
Norge	14
Belgium	16
Övrigt	17
NRA	17
100m	18
200m	18
NSRA	19
Danmark	19
Final	19
Italy	22
Austria	23
Jakt	33
Finland	37
10m	37
100m	37
Skandinavien	39
Military	39
Major	39
Minor	40
Full Bore	42
Norge	43
B	43
C	44
1/x	45
Övrigt	46
USA	49
Luft	49

SIUS

Innehåll

Svenska

Sida

Finkaliber	49
Pistol	50
Gevär	51
Jakt	52

Program

10m

ISSF	53
Rörligt mål	53
Femkamp	53
Övrigt	54
Final Luftgevär 10.9	54
Ljussignal	54
Italy	55
Sui	55
Luftgevär 10	55
Luftpistol 10	55

25m

ISSF	56
CISM	56
Sui	56
25RAP	56
PP10	57
O10	57
Danmark	58
Finkaliber	58
Grovkaliber	58
Övrigt	58

50m

58

SIUS

Innehåll

	Svenska
	<small>Sida</small>
ISSF	58
CISM	59
Rörligt mål	59
ISSF	60
ISSF Vildsvin	60
(Ringar)ISSF Vildsvin	60
DJV	60
SWE	60
Sui	60
Gevär	60
A5	60
A10	61
A20	61
A100	61
Pistol	62
PA4	62
PB5	62
PA10	62
PA100	63
Danmark	64
FRA	64
Övrigt	64
300m	64
ISSF	64
CISM	64
Schweiz	64
OP	64
Lag mästerskap	65
A	65
B	70
Övrigt	72

SIUS

Innehåll

	Svenska
	Sida
FS	72
Gams	73
F5	73
Skandinavien	73
Övrigt	74
Övrigt	74
50ft	74
200m	74
C200	74
A10 Reduced 200	75
NRA	75
Full Bore	75
Austria	75
Skandinavien	78
Militär	78
Jakt	78
USA	78
ISSF	78
10m	78
25m	79
50m	79
NCAA	79
Junior	80
Stående	80
Övrigt	80
CMP	80
NMAR	80
Pistol	80
President's Course	80

SIUS

Innehåll

Svenska

Sida

National Match Course 81

Gevär 81

President's Course 81

National Match Course 81

NRA 81

Pistol 82

National Match Course 82

Short Course 82

Camp Perry Course 82

Marksman League Course 82

Gallery Course 82

Gevär 83

National Match Course 83

Regional Course 83

Norge 83

Gevär 83

DFS 15m 83

A 83

B 84

Pistol 84

Hurtigpistol 84

NAIS 84

Kontrollera 85

Zoom 85

TOTAL 86

Resultat 86

Skärmkopia 86

Repetera 86

SC-Programs 86

SIUS

Innehåll

Svenska

Sida

86

Felfunktion

Övrigt

87

Avbryt

87

Radera tavlan

87

Timer

87

Ställ in timer

88

Starta timer

88

Nollställ timer

88

Ta bort timer

88

Target Lifter

88

System

90

Rapport

90

Föreg. serie

90

Skrivt ut

90

Skotträknare

91

Ogiltigt skott

91

Log

92

Inställningar

92

Presentation

92

Skott

92

Sista skott

92

Symbol

92

Form

92

Storlek

93

Invertera

94

Last Shot Window

94

Visa

94

Deferred Shots

94

Visa 10X

94

Standard

95

Symbol

95

SIUS

Innehåll

	Svenska
	Sida
Form	95
Storlek	95
Invertera	96
Utskriftsformat	96
Use Always	96
Visa format	97
Tiondel	97
Radera tavlan efter skott	98
Kors skott	98
Ogiltigt skott	98
Bästa skott	99
Skriver	99
Kolumnkonfiguration	99
Use Always	99
Skriv ut skjutprotokoll	99
Tiondel	100
Provskott	100
Delsumma	100
Print Overtime	100
Print number of Innertens	100
Antal tomrader	100
Grupp	102
Nollställa skottnummer	102
Delsumma	103
Övrigt	103
Manöverenhet	103
Layout	103
Funktions tangenter	103
Status blinkar	104
Övningsfönster	104
Large font in Listwindow	104
Meddelande	104
Visa meddelanden	104
Info tavelmatning	105
Visa figurnamn	105
Kaliber	105
Indikera	105

SIUS

Innehåll

	Svenska
	Sida
Parametrar	106
MTP	106
Text	106
MTP	106
Simulera resultattavla	106
Divisor	106
Språk	107
Språk	107
Tid	108
Justera tid	108
Datumformat	109
Övrigt	109
Start	109
Möjliggöra Repetering	109
återställa fria serier	109
Automatisk uppstart	110
SC-Programs	110
Single Execution	110
Scale Factor	110
Set Scale Factor	110
Target Alternative	110
Automatisk nollställning	110
Filter	111
Distans	111
Kategorie	112
Vapen	113
Användar grupp	114
Funktion	115
Mode	116
Kaliber	117
Use Always	117
Control Mode	118
Demo	118

SIUS

Innehåll

	Svenska
	Sida
Kontroll inställningar	119
Underhåll	119
Rapport	119
Inställningar	119
Skotträknare	120
Ogiltigt skott	120
Log	120
Debug	121
BIT-test	121
Taveltest	122
Tangentbord	122
Resultattavla	122
Nollställa monitor	122
Hårdvara	123
Resultattavla	123
Resultattavla	123
Manöverenhet	123
Meny	130
Set subnet	133
RC92	133
Match Meny	133
Figur	133
Figur byte	133
Bandmatning	133
Use Always	134
Target Lifter	134
Anslut	135
Light	135
Distance Index	135

SIUS

Innehåll

Svenska

Sida

Känslighet	136
Use Always	136
Time Control Unit	136
Time Control Unit	136
Duell mode	136
Graphic Printer Modell	136
Skott sensor	137
Logga in	138
Info	138
Krav	138
Legalisering	138
ange vapen	138
Ange ställning	139
Skytt ID krav	139
Legalisering	139
Vapentyp	140
Ställning	141
Skytt nummer	141

SIUS

Figurer


Free series are programs which do not prescribe any set numbers of shots. They are especially suitable for completing open training courses. With free series all official shoots can be simulated.

10m

The directory 10m is the compilation of all target images which typically are used over a distance of 10 metres.

ISSF

Officiella ISSF tavlor listas i denna sammanställning.




Luftgevär

10 m luftgevärstavla; ISSF reglemente Sektion 6.3.2.3; diameter 45,5mm; svart riktprick från ring 4 till 9



06000019000201(62)



Luftpistol


10 m luftpistolstavla; ISSF reglemente Sektion 6.3.2.6; diameter 155,5mm; svart riktprick från ring 7 till 10



06000019000203(56)

Schweiz

Targets that are used only in Switzerland are stored in this directory.




Luftgevär

10 metre target with the dimensions of the official ISSF target. But unlike the latter, with the secondary score in one hundredth rings instead of the one tenth ring score of the ISSF.



06000019000205(50)




Luftpistol

10 metre target with the dimensions of the official ISSF target. But unlike the latter, with the secondary score in one hundredth rings instead of the one tenth ring score of the ISSF.



06000019000207(44)



Volkscheibe


A 10 air rifle target with large 10-er ring for public events.



06000019000209(38)

Rörligt mål

The target pictures for the running target are filed in this directory. The discipline is also supported in the 10 metres by the ISSF.




Standard

10 m löpande target; ISSF reglemente Sektion 6.3.2.7.2; diameter 50,5mm; svart riktprick från ring 5 till 10



06000019001200(72)



Final


10 m löpande target; ISSF reglemente Sektion 6.3.2.7.2; diameter 50,5mm; svart riktprick från ring 5 till 10



06000019001201(69)

Skidskytte

Skidskyttetavlor redovisas här. Skidskyttetavlor återfinns under 10m och 50m.




15

Tavla med 15 mm diameter.



06000019001302(57)




20

Tavla med 20 mm diameter.



06000019001301(60)




35

Tavla med 35 mm diameter.



06000019001300(63)

Övrigt




Zimmerstutzen

German target



06000019000210(35)




Croatian AR Target



06000019000211(32)


Divisions



Luftgevär 10



06000019002600(43)




Luftpistol 10



06000019002601(40)

Italy



10m Rapid Fire




06000019000212(29)

25m

The directory 25m is the compilation of all target images which typically are used over a distance of 25 metres.

ISSF

Officiella ISSF tavlor listas i denna sammanställning.




Precision

25 / 50 metre precision pistol target PP10; ISSF Rules, Section 6.3.2.5, Diameter 500mm; black reflector from ring 7 to ring 10



06000019000303(47)



Automateld


25 metre rapid fire target, ISSF Rules, Section 6.3.2.4, Diameter 500mm; black reflector from ring 5 to 10



06000019000305(41)

Schweiz

Targets that are used only in Switzerland are stored in this directory.



O10


Swiss ordnance rapid fire pistol target (military); outline with ovals; Form 34.17



06000019000407(26)

Grovpistol

Många 25m tavlor används också för grovkaliberpistol (9,65mm). För att tolkningen skall bli korrekt vald listas dessa tavlor två gånger.




Precision

25 / 50 metre precision pistol target PP10; ISSF Rules, Section 6.3.2.5, Diameter 500mm; black reflector from ring 7 to ring 10



06000019000311(23)




Automateld

25 metre rapid fire target, ISSF Rules, Section 6.3.2.4, Diameter 500mm; black reflector from ring 5 to 10



06000019000313(17)



O10


Swiss ordnance rapid fire pistol target (military); outline with ovals; Form 34.17



06000019000707(96)

Russia

Targets that are used only in Switzerland are stored in this directory.




Russian No. 04

Swiss ordnance rapid fire pistol target (military); outline with ovals; Form 34.17



06000019003000(07)



Unterhebelrepetierer




06000019002702(28)

50m

The directory 50m is the compilation of all target images which typically are used over a distance of 50 metres.

ISSF

Officiella ISSF tavlor listas i denna sammanställning.




Gevär

50 m precisionstavla gevär; ISSF reglemente Sektion 6.3.2.2; diameter 154,4mm; svart riktprick från del av ring 3 till ring 10, diameter 112,4mm




06000019000301(53)



Final



06000019000302(50)



Pistol

25 / 50 metre precision pistol target PP10; ISSF Rules, Section 6.3.2.5, Diameter 500mm; black reflector from ring 7 to ring 10




06000019000303(47)

Schweiz

Targets that are used only in Switzerland are stored in this directory.

Gevär




A5

50 metre small calibre rifle target with five rings; diameter 154.4mm; black reflector from one section of ring 2 to ring 5.



06000019000307(35)




A10

50 m precisionstavla gevär; ISSF reglemente Sektion 6.3.2.2; diameter 154,4mm; svart riktprick från del av ring 3 till ring 10, diameter 112,4mm



06000019000308(32)




A20

50 metre precision rifle target; diameter 154.4mm; black reflector from one section of ring 6 to 20, diameter 112.4mm



06000019000309(29)



A100


50 metre precision rifle target with a one hundred ring score instead of the ISS ten ring score; diameter 154.4mm; black reflector diameter 112.4mm



06000019000310(26)

Finkaliber

Swiss pistol targets with small calibre (5.6mm) setting.




PA4

Pistol target A40; circular target with four rings.



06000019000401(44)




PA10

Pistol target A10; circular target with ten rings.



06000019000402(41)




PA100

Pistol target A100; circular target with one hundred rings.



06000019000403(38)




PB5

Pistol target B5; circular target with five equal rings and an outline whereby the outline is worth at least three points.



06000019000404(35)




PB10

Pistol target B10; circular target with ten equal rings and an outline.




06000019000405(32)



PB100
Pistol target B100; circular target with one hundred equal rings and an outline.



06000019000406(29)




O10
Swiss ordnance rapid fire pistol target (military); outline with ovals; Form 34.17



06000019000407(26)

Grovkaliber


Grovpistol



PA4
Pistol target A40; circular target with four rings.




06000019000701(17)



PA10
Pistol target A10; circular target with ten rings.




06000019000702(14)



PA100
Pistol target A100; circular target with one hundred rings.




06000019000703(11)




PB5
Pistol target B5; circular target with five equal rings and an outline whereby the outline is worth at least three points.




06000019000704(08)




PB10
Pistol target B10; circular target with ten equal rings and an outline.



PB100
Pistol target B100; circular target with one hundred equal rings and an outline.



O10
Swiss ordnance rapid fire pistol target (military); outline with ovals; Form 34.17




Morgarten
Outline target with five scores, whereby the value two is assigned to five ellipses and the value one to the rest of the outline.




Skidskytte

Skidskyttetavlor redovisas här. Skidskyttetavlor återfinns under 10m och 50m.




35mm
Tavla med 35 mm diameter.



45mm
Tavla med 45 mm diameter.






85mm
Tavla med 85 mm diameter.



06000019001304(51)




110
Tavla med 110 mm diameter.



06000019001303(54)


Divisions



Gevär



06000019002602(37)




Pistol



06000019002603(34)

Rörligt mål

The target pictures for the running target are filed in this directory. The discipline is also supported in the 10 metres by the ISSF.




Standard



06000019001208(48)

FRA



C50




06000019002708(10)

300m

The directory 300m is the compilation of all target images which typically are used over a distance of 300 metres.

ISSF

Officiella ISSF tavlor listas i denna sammanställning.




A10



06000019000002(77)

CISM

A10 tavlor som används inom de militära tävlingarna skiljer sig inte från de A10 tavlor som används i ISSF discipliner. För att filterfunktionen skall kunna utnyttjas bättre är kategorin CISM upplagd separat.



A10




06000019000002(77)

Schweiz

Targets that are used only in Switzerland are stored in this directory.

A


A-targets with varied scores:



A5




06000019000001(80)



A6




06000019000005(68)



A10




06000019000002(77)



A100




06000019000003(74)



A10/FA10



06000019000014(41)




Final A10



06000019000015(38)

B


B-targets with different scores (field target B Form. 34.21.2.88):



B4




06000019000004(71)



B10




06000019000008(59)



B100




06000019000009(56)



PB5
Pistol target PB5



06000019000010(53)



F5




06000019000007(62)

Skandinavien

Targets that are used only in Scandinavia are stored in this directory. The exception is animal images (moose and reindeer) which can be found under 'OtherHuntingMoose'.


Norge



Nor7




06000019001101(78)



Nor8




06000019001102(75)



NSF 15m




06000019001410(24)



DFS 15m




06000019001411(21)



DFS100




06000019001103(72)



DFS 200




06000019001412(18)



DFS 300




06000019001413(15)



Nya Svenska




06000019001100(81)



16FIG




06000019001105(66)



16V




06000019001106(63)



C30



06000019001104(69)




A10 Reduced 200



06000019001414(12)


Belgium



A10




06000019000002(77)



Oly100




06000019001501(42)



Oly200




06000019001502(39)



Schijf K




06000019001503(36)



Schijf 4




06000019001504(33)



Schijf 5




06000019001505(30)



Schijf S




06000019001506(27)



NTTC4



06000019001507(24)



NTTC5




06000019001508(21)

Övrigt

All targets that do not clearly fall under one of the preceding distances are included in the category 'Other'.


NRA



50ft Rifle Target




06000019002803(16)



SR2 200y




06000019002805(10)



MR1 600y




06000019002806(07)



Short Range




06000019002800(25)



Long Range



06000019002801(22)




Combined Range



06000019002802(19)


100m



AUT 100m KK



06000019002701(31)




Schijf Woerden



06000019002700(34)

200m




C200



06000019002707(13)


NSRA



NSRA 15y



06000019003600(50)




NSRA 15y Final



06000019003601(47)

Danmark


Final



50m riffel M 90 F




06000019002906(95)



15m riffel 1984 F




06000019002907(92)



15m fripistol F




06000019002908(89)



15m luftriffel M 96/G F




06000019002909(86)



15m pistol F




06000019002910(83)



15m riffel D SkyU 1982 F




06000019002911(80)



10-delt figurskive (S3)




06000019003512(23)



50m riffel M 90




06000019002900(16)



15m riffel 1984




06000019002901(13)



15m luftriffel M 96/G




06000019002903(07)



15m riffel DskyU 1982




06000019002905(01)



15m fripistol




06000019002902(10)



15m pistol




06000019002904(04)



Airpistol 10 Rim




06000019003510(29)



AZF047




06000019002912(77)



AZF048




06000019002913(74)



10-delt figurskive (S3)




06000019003511(26)



A10 Reduced 200



06000019001414(12)




C30



06000019001104(69)


Italy



Bersaglio 1




06000019002400(61)



Bersaglio 2




06000019002401(58)



Bersaglio 9




06000019002402(55)



P1




06000019002403(52)



P2




06000019002404(49)



P3




06000019002405(46)



A10 100m




06000019002406(43)



A10 200m



06000019002407(40)



A10 300m




06000019002408(37)

Austria

ASR


\ASR\Pistol



Pistol A 5m




06000019001700(27)



Pistol A 10m




06000019001701(24)



Pistol B 5m




06000019001702(21)



Pistol B 10m




06000019001703(18)



Pistol D 5m




06000019001704(15)



Pistol D 10m




06000019001705(12)



Pistol C 7m




06000019001706(09)



Pistol C 15m




06000019001707(06)



Pistol C All




06000019001708(03)



Pistol E 20m



06000019001709(97)




Pistol E All



06000019001710(94)


VASR\Gevär



Rifle A 10m vertical




06000019001602(30)



Rifle A 20m vertical




06000019001603(27)



Rifle B 10m horizontal




06000019001604(24)



Rifle B 20m horizontal




06000019001605(21)



Rifle B 10m ellipse




06000019001606(18)



Rifle B 20m ellipse




06000019001607(15)



Rifle C 15m




06000019001608(12)



Rifle C 30m




06000019001609(09)



Rifle C All




06000019001610(06)



Rifle D 40m



06000019001611(03)




Rifle D All



06000019001612(97)

Klassisk


\Klassisk\Pistol



A10




06000019001810(85)



A100




06000019001811(82)



Klein links




06000019001801(15)



Klein rechts




06000019001802(12)



Gross links




06000019001803(09)



Gross rechts




06000019001804(06)



Klein Klein




06000019001805(03)



Klein Gross




06000019001806(97)



Gross Klein




06000019001807(94)



Gross Gross



06000019001808(91)




Precision

25 / 50 metre precision pistol target PP10; ISSF Rules, Section 6.3.2.5, Diameter 500mm; black reflector from ring 7 to ring 10



06000019001812(79)


\Klassisk\Gevär



R10




06000019001800(18)



A10




06000019000002(77)



A100



06000019000003(74)




Anschluss Scheibe



06000019001809(88)

\Klassisk\MG


\Klassisk\MG\A



MG Ziel A1




06000019001900(09)



MG Ziel A2




06000019001901(06)



MG Ziel A3




06000019001902(03)



MG Ziel A4




06000019001903(97)



MG Ziel A5




06000019001904(94)



MG Ziel A6




06000019001905(91)



MG Ziel A7



06000019001906(88)




MG Ziel A8



06000019001907(85)


\Klassisk\MG\B

MG Ziel B1




06000019001908(82)

MG Ziel B2




06000019001909(79)

MG Ziel B3




06000019001910(76)

MG Ziel B4




06000019001911(73)

MG Ziel B5




06000019001912(70)

MG Ziel B6




06000019001913(67)

MG Ziel B7



06000019001914(64)


MG Ziel B8



06000019001915(61)


\Klassisk\MG\C

MG Ziel C1




06000019002000(97)

MG Ziel C2




06000019002001(94)

MG Ziel C3




06000019002002(91)

MG Ziel C4




06000019002003(88)

MG Ziel C5




06000019002004(85)

MG Ziel C6




06000019002005(82)

MG Ziel C7



06000019002006(79)

MG Ziel C8



06000019002007(76)

Jakt

Älg

Summary of the moose targets:

Älg\Vänster

Älg 5-5-4-3


Moose target with the scores 5-5-4-3 and 10-8-6-4.



06000019001401(51)

Älg 10

Moose target with tenner score.



06000019001404(42)

Älg SWE (Gammal)

(Gammal)



06000019001407(33)

Älg SWE

Swedish moose target with 5-5-4-3 score.



06000019002504(40)

Älgkalv

Swedish Elk calf target with 5-5-4-3 and Hit-Score




06000019001409(27)

VälgHöger

Älg 5-5-4-3


Moose target with the scores 5-5-4-3 and 10-8-6-4.



06000019001402(48)

Älg 10

Moose target with tenner score.



06000019001405(39)

Älg SWE (Gammal)


(Gammal)



06000019001408(30)

Älg SWE

Swedish moose target with 5-5-4-3 score.



06000019002503(43)

Älgkalv

Swedish Elk calf target with 5-5-4-3 and Hit-Score




06000019001415(09)

VälgDubbel

Älg 5-5-4-3


Moose target with the scores 5-5-4-3 and 10-8-6-4.



06000019001400(54)

Älg 10


Moose target with tenner score.



06000019001403(45)

Älg SWE (Gammal)

(Gammal)




06000019001406(36)

Gris

Summary of bore targets:

Gris 5


Running target 50 metre (ISSF-Bore 5; DJV No. 5);
ISSF Rules Section 6.3.2.7.1
Diameter 60mm



06000019000110(44)

Gris 5 höger


Running target 50 metre (ISSF-Bore 5; DJV No. 5);
ISSF Rules Section 6.3.2.7.1
Diameter 60mm



06000019000104(62)

Gris 2


DJV Number 2; Bore Art. No. S100AA010V1



06000019001514(03)

Vildsvin höger SWE


Swedish wild boar target.



06000019002507(31)

Vildsvin vänster SWE

Swedish wild boar target.




06000019002508(28)

Björn


Bear Target

Björn vänster




06000019001213(33)

Björn höger



06000019001214(30)


Björn front



06000019001215(27)

Övrigt


Bear Target



Kronhjort




06000019002500(52)



Råbock vänster




06000019002501(49)



Råbock höger



06000019002502(46)




Råbock Ringar



06000019001510(15)

\Övrigt\Finland


\Övrigt\Finland\10m



Bird 10m Finland



06000019003100(95)




Moose 10m Finland



06000019003102(89)


\Övrigt\Finland\100m



Bird 100m Finland




06000019003101(92)



Moose 100m Finland



06000019003103(86)




Get

DJV Nummer 1; Chamois Art. No. S100AA008V1



06000019000108(50)




Räv

DJV Nummer 2; Fox Art. No. S100AA009V1



06000019000106(56)




Rådjur

DJV Nummer 4; Råbock Art. No. S100AA007V1




06000019000102(68)



DJV9 Rothirsch




06000019003901(20)



Dansk Råbock



06000019000115(29)




Ren

Reindeer DV-I Norway; Art. No. S100AA012



06000019000114(32)




Rådjur Hubertus

Hubertus Rådjur



06000019000112(38)




Gems Hubertus

Hubertus Gams rechtslaufend (Spezialscheibe für Kanton St. Gallen)



06000019000113(35)



Precision

25 / 50 metre precision pistol target PP10; ISSF Rules, Section 6.3.2.5, Diameter 500mm; black reflector from ring 7 to ring 10




06000019000303(47)

Skandinavien

Targets that are used only in Scandinavia are stored in this directory. The exception is animal images (moose and reindeer) which can be found under 'Other\Hunting\Moose'.

Militär


\Militär\Major



PEK2




06000019003700(41)



IPSC Combi 2




06000019003704(29)



Pistolman from right



06000019003706(23)




Pistolman from left



06000019003708(17)


\Militär\Minor



PEK2




06000019003701(38)



IPSC Combi 2




06000019003705(26)



Pistolman from right




06000019003707(20)



Pistolman from left




06000019003709(14)



Precision




06000019003710(11)



2x1/3 figur




06000019001112(45)



1/1+1/3 figur




06000019001113(42)



1/1 figur




06000019001107(60)



1/8+1/2 figur



06000019001114(39)




1/2 figur



06000019001108(57)


SIUS



1/3 figur



06000019001109(54)




1/8 figur



06000019001110(51)


Full Bore



300y




06000019002300(70)



500y




06000019002301(67)



600y



06000019002302(64)




300m



06000019002303(61)


SIUS



500m




06000019002304(58)



600m



06000019002305(55)



Long Range



06000019002306(52)


Norge

B

B45




06000019002210(49)



B65




06000019002211(46)



B100




06000019002212(43)



Smaen



06000019002213(40)




Minismaen



06000019002214(37)


C



C15




06000019002100(88)



C20




06000019002101(85)



C25




06000019002102(82)



C30





06000019002103(79)







C35







06000019002104(76)






1/x





Övrigt






Stripe




06000019002109(61)



Prisme




06000019002110(58)



S25




06000019002111(55)



Hjul




06000019002112(52)



150Sirkel




06000019002113(49)



55Sirkel




06000019002114(46)



40Tonne




06000019002208(55)



14Tonne




06000019002209(52)



NSF 15m




06000019001410(24)



DFS 15m




06000019003300(77)



DFS100




06000019003301(74)



DFS 200




06000019003302(71)



DFS 300



06000019003303(68)




Sprintluft



06000019003304(65)

USA

Luft




Luftpistol

10 m luftpistolstavla; ISSF reglemente Sektion 6.3.2.6; diameter 155,5mm; svart riktprick från ring 7 till 10



06000019000203(56)




Luftgevär

10 m luftgevärstavla; ISSF reglemente Sektion 6.3.2.3; diameter 45,5mm; svart riktprick från ring 4 till 9




06000019000201(62)



AR-SR



06000019002810(92)




AR-MR



06000019002811(89)

Finkaliber




50m

50 m precisionstavla gevär; ISSF reglemente Sektion 6.3.2.2; diameter 154,4mm; svart riktprick från del av ring 3 till ring 10, diameter 112,4mm




06000019000301(53)



50ft Rifle Target



06000019002803(16)




A17 50ft



06000019002812(86)


Pistol



B2 50ft slow




06000019003200(86)



B3 50ft rapid




06000019003201(83)



B4 20yd slow




06000019003202(80)



B5 20yd rapid




06000019003203(77)



B6 50yd slow




06000019003204(74)



B8 25yd rapid



06000019003205(71)




B16 25yd slow



06000019003206(68)


Gevär



SR1 100y




06000019002807(04)



SR2 200y




06000019002805(10)



SR3 300y




06000019002808(01)



MR1 600y




06000019002806(07)



LR1 1000yd




06000019002809(95)



Long Range



06000019002801(22)




Short Range



06000019002800(25)


Jakt



Rådjur vänster



06000019000102(68)



Gris 5 vänster



06000019000110(44)

Program

The programs are subdivided according to the usual distance, and according to categories of additional properties (e.g. Federation programs, group championships). The individual programs are designated with the target picture (e.g. A5), the type or fire (T=Test shots, S=Single fire, D=Serial fire) and the number of shots in this type of fire (T2 = 2 test shots, S5 = single fire 5 shots, D3 = serial fire 3 shots, T0 = test free/open, i.e. an open-ended number of test shots can be fired).

10m

The directory 10m is the compilation of all programs which typically are shot over a distance of 10 metres.

ISSF

Luftgevär 40



20000735(55)

Luftgevär 60



20000734(58)

Luftpistol 40



20000737(49)

Luftpistol 60



20000736(52)

Rörligt mål

3030



20000760(77)

2020




20000761(74)

Mixed



20000762(71)


Skidskytte



15mm



06000019001302(57)



20mm



06000019001301(60)

Femkamp

Femkamp 20



20000450(37)

Femkamp 3*10



20000460(07)

CE



20000451(34)

Provskott



20000452(31)

Övrigt

Final Luftgevär 10.9

Luftgevär 30



20000774(35)

Air Rifle 20



20000773(38)

Luftgevär 30



20000756(89)

Air Rifle 20



20000757(86)

Luftgevär 3*10



20000754(95)

Luftgevär 3*20



20000777(26)

Luftgevär 3*40



20000819(94)

Air Pistol 30



20000749(13)

Air Pistol 20



20000739(43)

Zimmerstutzen 30



20000748(16)

Ljussignal

Snabbpistol



20000765(62)

Standard Pistol 60



20000201(08)

Standard Pistol 40



20000202(05)

Standard Pistol 30



20000203(02)

Sportpistol



20000204(96)

Snabb



20000205(93)

Italy

P10Sp



20000206(90)

Sui

Luftgevär 10

P0 mit Druck



20000112(81)

P0 ohne Druck



20000113(78)

S0



20000114(75)

E10



20000115(72)

Luftpistol 10

P0 mit Druck



20000116(69)

P0 ohne Druck



20000117(66)

S0



20000118(63)

E10




20000119(60)





25m

The directory 25m is the compilation of all programs which typically are shot over a distance of 25 metres.

ISSF




Snabbpistol	 20000730(70)
Sportpistol	 20000733(61)
Grovpistol	 20000731(67)
Standardpistol	 20000732(64)

CISM

Sportpistol	 20000733(61)
Grovpistol	 20000731(67)
Military Rapid Fire Men	 20000750(10)
Military Rapid Fire Women	 20000753(01)

Sui

25RAP

P0 mit Druck	 20000142(88)
P0 ohne Druck	 20000143(85)
S0	 20000144(82)
E5	 20000145(79)
S5	 20000146(76)
S5D5	 20000147(73)
S5S5	 20000148(70)

D5D5D5



20000149(67)

P5 D5 D5 D5



20000150(64)

PP10

P0 mit Druck



20000151(61)

P0 ohne Druck



20000152(58)

S0



20000153(55)

S5S5



20000154(52)

S5S5



20000155(49)

P5 D5 D5



20000156(46)

O10

P0 mit Druck



20000157(43)

P0 ohne Druck



20000158(40)

S0



20000159(37)

S5S5



20000160(34)

S5S5



20000161(31)

S5 S5 S5



20000162(28)

D5D5D5



20000163(25)

S5 S5 S5 S5



20000164(22)

D5D5D5D5



20000165(19)

OP



20000830(61)

FS



20000831(58)

Feldstich



20000166(16)

Danmark

Finkaliber

DGI Finpistol



20000894(63)

Standardpistol



20000732(64)

Grovkaliber

DGI Finpistol grovpistol GPA



20000897(54)

Standard Pistol Gkal



20000893(66)

Övrigt

SP15



20000751(07)

Russian No. 04



20000865(53)

50m

The directory 50m is the compilation of all programs which typically are shot over a distance of 50 metres.

ISSF

Gevär 60



20000725(85)

Standardgevär 3*20



20000726(82)

Frigevär 3*40



20000724(88)

3 Positions Final



20000791(81)

Pistol 60



20000727(79)

Rifle 2*30



20000716(15)

CISM

Gevär 60




20000725(85)

Standardgevär 3*20



20000726(82)


Skidskytte



35mm




06000019001306(45)



45mm




06000019001305(48)



85mm



06000019001304(51)



110



06000019001303(54)

Rörligt mål

ISSF

\ISSF\ISSF Vildsvin

3030



20000770(47)

2020



20000771(44)

Mixed



20000772(41)

\ISSF\Ringar\ISSF Vildsvin

3030



20000822(85)

2020



20000824(79)

Mixed



20000826(73)

DJV

Gris 5



20000775(32)

SWE

Rörligt Råbock



20000851(95)

Råbock Ringar



20000849(04)

Mini Älg



20000852(92)

Älg vänster/höger



20000859(71)

Sui

Gevär

\Gevär\A5

P0S10



20000092(44)

P0 D5 D5



20000093(41)

\Gevär\A10

P0 mit Druck



20000094(38)

P0 ohne Druck



20000095(35)

S0



20000096(32)

E6



20000097(29)

E8



20000098(26)

E10



20000099(23)

S4 D2 D2



20000100(20)

E4 S3 S3



20000101(17)

S6 D2 D2



20000102(14)

D3D3D3



20000103(11)

Rifle 30 (15+15)



20000715(18)

\Gevär\A20

P0 mit Druck



20000167(13)

P0 ohne Druck



20000168(10)

S6S8S10



20000104(08)

\Gevär\A100

P0 mit Druck



20000105(05)

P0 ohne Druck



20000106(02)

S0



20000107(96)

Nachdoppel



20000360(16)

E3



20000108(93)

E5



20000109(90)

E6



20000110(87)

E10



20000111(84)

Pistol

OP



20000832(55)

\Pisto\PA4

P0 mit Druck



20000120(57)

P0 ohne Druck



20000121(54)

S0



20000122(51)

\Pisto\PB5

P0 mit Druck



20000123(48)

P0 ohne Druck



20000124(45)

S0



20000125(42)

FS



20000833(52)

\Pisto\PA10

P0 mit Druck



20000126(39)

P0 ohne Druck



20000127(36)

S0



20000128(33)

E6



20000129(30)

E8



20000130(27)

E10



20000131(24)

P0S10D5



20000132(21)

B-Match



20000133(18)

\Pisto\PA100

P0 mit Druck



20000134(15)

P0 ohne Druck



20000135(12)

S0



20000136(09)

Nachdoppel



20000137(06)

E3



20000138(03)

E5



20000139(97)

E6



20000140(94)

E10



20000141(91)

Morgarten



20000361(13)

Danmark

40-60-40



20000456(19)

20-60-20



20000455(22)

FRA

TAR 50m



20000872(32)

Övrigt

Gevär 3*10



20000755(92)

Rifle 30



20000758(83)

Rifle 20



20000714(21)

300m

The directory 300m is the compilation of all programs which typically are shot over a distance of 300 metres.

ISSF

Frigevär 3*40



20000721(97)

Frigevär 60



20000722(94)

Standardgevär 3*20



20000723(91)

CISM

Standardgevär 3*20



20000723(91)

Rapid Fire 3x20

*Military Rapid Fire 3*20*



20000816(06)

Schweiz

OP

Komplett



20000840(31)

OP A5 Prov



20000839(34)

OP A5 Dela 1

A5 S5



20000838(37)

OP B4 Prov



20000836(43)

OP B4 Dela 2

B4 S5 D2 D3 D5



20000837(40)

Lag mästerskap

A5S

Obegränsat antal provskott på tavla A5



20000398(96)

A10S

Obegränsat antal provskott på tavla A10



20000397(02)

Fält A

GM Feld A



20000084(68)

Fält B

GM Feld B



20000014(84)

Fält C

Gm Feld D



20000083(71)

A

\A\A5

P0 mit Druck



20000011(93)

P0 ohne Druck



20000085(65)

\A\A5\Enkelskott

E4



20000019(69)

E5



20000012(90)

E6



20000013(87)

E8



20000020(66)

E10



20000015(81)

\A\A5\Dolda skott

S0



20000010(96)

S5



20000023(57)

S6



20000024(54)

S3S3



20000025(51)

S4S4



20000026(48)

S5S5



20000016(78)

\A\A5\Dolda skott\Med provskott

P2 S2 S3 S5



20000344(64)

P1 S2 S3 S4 S5



20000346(58)

P2 S2 S2 S3 S3



20000348(52)

\A\A5\Kombinerad

E4S4



20000006(11)

E5S3



20000021(63)

E2 S3 S5



20000009(02)

E4 S3 S3



20000022(60)

E5 S3 S4



20000007(08)

E6 S3 S3



20000676(38)

E2 S2 S3 S5



20000008(05)

\A\A5\Kombinerad\Med provskott

E6S4



20000002(23)

P2 E1 S3 S6



20000027(45)

P2 E2 S3 S3



20000668(62)

P2 E2 S3 S5



20000003(20)

P2 E5 S3 S4



20000667(65)

P3 E6 S3 S3



20000001(26)

P2 S2 S2 S3 S3



20000005(14)

P1 E2 E3 E4 E5



20000004(17)

\A\A10

P0 mit Druck



20000031(33)

P0 ohne Druck



20000086(62)

\A\A10\Enkelskott

E5



20000033(27)

E6



20000034(24)

E8



20000035(21)

\A\A10\Enkelskott\Med provskott

Opening shooting



20000763(68)

P2E6



20000666(68)

P2S10



20000029(39)

P2S6S4



20000038(12)

\A\A10\Dolda skott

S0



20000030(36)

S5



20000043(94)

S6



20000044(91)

S3S3



20000045(88)

S5S5



20000090(50)

\A\A10\Dolda skott\Med provskott

P2S1



20000694(81)

P2 S2 S3 S5



20000040(06)

P2 4*S5



20000028(42)

\A\A10\Kombinerad

E3S3



20000041(03)

E4S4



20000042(97)

E5S3



20000046(85)

E6S4



20000032(30)

E2 S3 S5



20000039(09)

E2 S3 S5



20000357(25)

E4 S3 S3



20000210(78)

E3 E4 S4 S4



20000677(35)

\A\A10\Kombinerad\Med provskott

E4S4



20000047(82)

E5S3



20000037(15)

E6S6



20000048(79)

P2 E5 S2 S3



20000356(28)

P2 4*S5



20000695(78)

Liggande 4*E10



20000589(08)

Stående 4*E10



20000579(38)

Knä 4*10



20000569(68)

\A\A100

P0 mit Druck











20000051(70)

P0 ohne Druck



20000087(59)

\A\A100\Enkelskott

E2 <i>Nachdoppel</i>	 20000052(67)
E3	 20000053(64)
E4	 20000054(61)
E5	 20000055(58)
E6	 20000056(55)
E10	 20000057(52)
S15	 20000088(56)
P1E4	 20000665(71)
S0	 20000050(73)
S4S4	 20000049(76)
P2 E5 S2 S3	 20000058(49)

B

\B\B4

P0 mit Druck	 20000061(40)
P0 ohne Druck	 20000089(53)
E6	 20000062(37)
\B\B4\Dolda skott	
S0	 20000060(43)

S5



20000064(31)

S6



20000063(34)

S3S3



20000065(28)

S4S4



20000066(25)

P2 S4 S6 KOM



20000349(49)

\B\B4\Kombinerad

E3 S3 S3



20000067(22)

E3 S3 S6



20000379(56)

E3 S3 S3 S3



20000069(16)

E4S4



20000345(61)

Feldstich



20000091(47)

\B\B4\Kombinerad\Med provskott

P2 E1 E3 E6



20000068(19)

P2 E2 S3 S5



20000669(59)

E4S4



20000070(13)

P2 E6 S6 S6



20000075(95)

\B\B10

P0



20000968(35)

E0



20000076(92)

S0



20000077(89)

E2 S3 S5



20000376(65)

E2S2



20000078(86)

S3S5



20000079(83)

\B\B100

P0



20000967(38)

E0



20000081(77)

S0



20000080(80)

E10



20000082(74)

\B\PB5

P0



20000394(11)

E0



20000071(10)

S0



20000073(04)

S4S6



20000072(07)

Övrigt

FS



20000059(46)

Knabenschiessen

The youth shooting practice is solely for the Zurich Youth Shoot. Therefore it has a special score (A6) and a special printout. In youth shooting 5 shots are fired at an A5 target. The innermost ring (5-er ring) is valued with 6 points. The outermost ring counts for 2



20000399(93)

points instead of 1 point. Each hit outside the outermost ring that nonetheless hits the target counts for 1 point. Moreover at the end each target hit is further awarded 1 point and this sum is included in the total result. The maximum is therefore 5 x 6 points + 5 hits = 35 points.

Morgarten



20000362(10)

Pfäffiker winterprogram

Hit score for single firer: every 10 shots in 10-er score; for group score 2. Pass (E4) in 100-er score.



20000377(62)

Ustertag-Scheibe



20000738(46)

Vögelinsegg



20000363(07)

Hans Waldmann Schiessen



20000776(29)

Endschiessen



20000170(04)

\Övrigt\Gams

Opening shooting



20000596(84)

Grümpel Stich



20000597(81)

F5

S0



20000976(11)

E0



20000986(78)

Skandinavien

Svenskt skjutprogram

Dubbel

P0 S5 S5 S5 S5



20000718(09)

10

P0 S5 S5



20000719(06)

25

P0 S5 S5 S5 S5 S5



20000720(03)

Svenskt mästerskap

Grundomgång
P0 S5 S5 S5



Mellan omgång
P0 S5 S5



Final
P0 S5 S5



Reserverad
P0 S5 S5 S5 S5



Final reserverad
P0 S5 S5 S5



Övrigt

Rifle 2*30



Gevär 3*10



Rifle 20



Övrigt

All targets that do not clearly fall under one of the preceding distances are included in the category 'Other'.

50ft

50ft Rifle 3x40



50ft Rifle 3x20



200m

C200

C200 60



C200 3x20



TAR 200m



A10 Reduced 200

Frigevär 60



20000866(50)

Standardgevär 3*20



20000867(47)

NRA

MR1 600y



20000925(67)

Short Range



20000920(82)

Long Range



20000921(79)

Combined Range



20000922(76)

Full Bore

3yDL



20000860(68)

5yDL



20000861(65)

6yDL



20000862(62)

LRDL



20000863(59)

Austria

Pistol

\Pistol\1

1

Pistol A 5m



20000500(81)

Pistol A 10m



20000501(78)

\Pistol\2

2

Pistol B 5m



20000502(75)

Pistol B 10m



20000503(72)

\Pistol\3

3

Pistol D 5m



20000504(69)

Pistol D 10m



20000505(66)

\Pistol\4

4

Pistol D 5m



20000504(69)

Pistol D 10m



20000505(66)

5

5



20000504(69)

6

6



20000504(69)

7

7



20000506(63)

8

8



20000508(57)

9

9



20000508(57)

10

10



20000507(60)

11

11



20000509(54)

12

12



20000510(51)

Gevär

\Gevär\5

5

Rifle A 10m vertical



20000511(48)

Rifle A 20m vertical



20000512(45)

\Gevär\6

6

Rifle B 10m horizontal



20000513(42)

Rifle B 20m horizontal



20000514(39)

\Gevär\7

7

Rifle B 10m ellipse



20000515(36)

Rifle B 20m ellipse



20000516(33)

\Gevär\8

8

Rifle B 10m ellipse



20000515(36)

Rifle B 20m ellipse



20000516(33)

9

9



20000515(36)

10

10



20000515(36)

11

11



20000515(36)

12

12



20000519(24)

13

13



20000519(24)

\Gevär\14

14

Rifle C 15m



20000517(30)

Rifle C 30m



20000518(27)

15

15



20000520(21)

16

16



20000521(18)

Skandinavien

Targets that are used only in Scandinavia are stored in this directory. The exception is animal images (moose and reindeer) which can be found under 'Other\Hunting\Moose'.

Militär

2x1/3 figur



20000740(40)

1/1+1/3 figur



20000741(37)

1/1 figur



20000742(34)

1/8+1/2 figur



20000743(31)

1/2 figur



20000744(28)

1/3 figur



20000745(25)

1/8 figur



20000746(22)

Precision



20000747(19)

Jakt

Älg



20000850(01)

Älg vänster/höger



20000853(89)

Vildsvin v/h SWE

Swedish wild boar target.



20000858(74)

USA

The directory 10m is the compilation of all programs which typically are shot over a distance of 10 metres.

ISSF

10m

Luftgevär 40



20000735(55)

Luftgevär 60



20000734(58)

Luftpistol 40



20000737(49)

Luftpistol 60



20000736(52)

25m

Snabbpistol



20000730(70)

Sportpistol



20000733(61)

Grovpistol



20000731(67)

Standardpistol



20000732(64)

50m

Gevär 60



20000725(85)

Standardgevär 3*20



20000726(82)

Frigevär 3*40



20000724(88)

3 Positions Final



20000791(81)

Pistol 60



20000727(79)

NCAA

NCAA AR60



20000470(74)

50ft Rifle 3x20



20000841(28)

50Ft 3Position Final



20000864(56)

Junior

Stående

Luftgevär 40



20000735(55)

Luftgevär 60



20000734(58)

ARS2x20



20000607(51)

ARS3x20



20000608(48)

Final



20000471(71)

Övrigt

Luftgevär 3*10



20000754(95)

Luftgevär 3*20



20000766(59)

Junior 4P



20000612(36)

Junior 4P Final



20000600(72)

CMP

NMAR

NMAR - Half Course



20000609(45)

NMAR - Full Course



20000610(42)

NMAR - Sporter Garand



20000611(39)

Pistol

\Pistol\President's Course

1



20000613(33)

2



20000614(30)

3



20000615(27)

\Pistol\National Match Course

1



20000616(24)

2



20000617(21)

3



20000618(18)

Gevär

\Gevär\President's Course

1



20000619(15)

2



20000620(12)

3



20000621(09)

Final



20000650(19)

\Gevär\National Match Course

1



20000622(06)

2



20000623(03)

3



20000624(97)

4



20000625(94)

NRA

Pistol

\Pistol\National Match Course

1



2



3



\Pistol\Short Course

1



2



3



\Pistol\Camp Perry Course

1



2



3



\Pistol\Marksman League Course

1



2



3



\Pistol\Gallery Course

1



2



3



20000637(58)

4



20000638(55)

5



20000639(52)

6



20000640(49)

Gevär

\Gevär\National Match Course

1



20000641(46)

2



20000642(43)

3



20000643(40)

4



20000644(37)

\Gevär\Regional Course

1



20000645(34)

2



20000646(31)

3



20000647(28)

4



20000648(25)

5



20000649(22)

Norge

Gevär

DFS 15m

\DFS 15m\A

A ARE V65 V73 1 AG3



20000400(90)

A KI J 2 V55 Åpen



20000403(81)

A KI 3 4 5



20000406(72)

\DFS 15m\B

B ARE V65 V73 1 AG3



20000409(63)

B KI J 2 V55 Åpen



20000411(57)

B KI 3 4 5



20000413(51)

DFS100



20000415(45)

DFS 200



20000418(36)

DFS 300



20000421(27)

Pistol

Sprintluft



20000425(15)

Hurtigpistol

FinK



20000753(01)

GKal



20000750(10)

Fripistol B



20000424(18)

NAIS

FinK



20000426(12)

GKal



20000427(09)

Kontrollera

The control menu contains all the functions that are necessary during a running program. The menu pops up automatically into this view after a program is selected.

Zoom

Most target pictures can be represented in three different sizes (zoom levels). The zoom command switches to the next size. When the smallest size has been reached, then the next zoom command brings up the largest size again.



099052(52)

Match

In the course of a match, by means of the Match button (RC92) the major commands for controlling the match can be carried out by the firer. Thus the setting can be changed from the test group to the first single group. So long as the single group has not yet shot, triggering this command again can enable a return to the test group. In user practices and in free series this command does not appear in the menu. In this case (if the RC92 is pressed or if the corresponding barcode is input) a group total is triggered.



990636(75)

Provs katt

In free series the fire type can be restarted at any time with the commands Test, Single and Series.



99063400(49)

Enkelskott

In free series the fire type can be restarted at any time with the commands Test, Single and Series. If the fire type is already set to single, with this command the single group can be totalised and immediately a new group can be started. In this way for example every 10 shots a group total of an ISSF shoot can be simulated.



99063401(46)

Delsumma

Closes off the current open group and prints out a group total. The function is available only when an open group (P-, S- or D-) is shot. A group where the number of shots is prescribed cannot be skipped. If shooting takes place without a shot logoff, then shots which have totally missed the target must be reported to the system with the command 'Other\insert zero shot'.



990530(05)

Total

In a free series the group total corresponds to the intermediate total or to a position total. The current group is added up. This corresponds to a subtotal. In addition all the groups since the last group total are counted together and removed. Thereafter the group can be continued.



990531(02)

TOTAL

In a free series the match total stops the current program (program total). It triggers a subtotal and a group total. In addition all shot values (except test shots) are added together and shown as the 'large' total. Other programs than the free series (match, user practice and fixed programs) cannot be stopped prematurely. They can only be broken off and filled



990532(96)

with manual nulls. An abort can be brought about by the command '\Other\Abort' or by loading another program. In the event of an abort the shot values are also added together and displayed.

Dolda skott

In free series the fire type can be restarted at any time with the commands Test, Single and Series. If the fire type is already set to Series, with this command the series group can be shown and totalised. Subsequently a new series group is automatically started.



99063402(43)

Visa

In a group with serial shots all shots fired up to the present moment are displayed in advance. Correspondingly at the end of the group, only those shots which have not yet been displayed are shown. In groups with the fire type Test or Single Shot the barcode has no effect.



099054(46)

Resultat

In free series the command Value can change the secondary score to the primary score. This is useful if first a qualifier and then a final are shot. At most official shoots the finals are scored in tenths, but the qualifiers are scored in whole tens. If the command is carried out a second time, then the original score is switched on again. With the commands '\Other\Next Primary Score' and '\Other\Next Secondary Score' the primary and secondary scores can be controlled.



990643(54)

Skärmkopia

The current screen content is printed on the graphic printer (Only D931/CBM210). It is not possible to print out on the dot matrix printer D93.



099050(58)

Repetera

Restarts a closed off practice with the same settings (firer number, firer name, weapon and position). This command can be blocked with the setting '\Other\Start\Permit Repeat(Off)'.



91(18)

SC-Programs

Omgång

In programs that show a match structure, under 'Group' it is possible to select which setting you want to begin with. In this way for example only the final of a match can be shot. During the match in progress, under 'Group' the setting 'Test' can be selected. This test corresponds to the regulated exceptional test which can be permitted after weapon malfunction. If the setting 'Test' is selected, then under 'Group' only the position that was shot most recently appears. Choosing this position enables you to return to the official match.

Felfunktion

In the 25m pistol disciplines, various rules are defined which lay down the procedures for weapon failures. According to the discipline and the type of weapon failure (allowable / non allowable) the fired shots must be completed and evaluated. Individual commands enable the system to correctly calculate the end result and to correctly show the individual shots on the screen as well as on the scoreboard.

Fylla serier

The active group is stocked with zeros. This also happens when the group have not yet shot.



99063700(22)

Införa skott '0'

Inserts a shot with the value 0 into the current program. This function is needed if shooting took place without the use of the shot sensor and the target was missed. The system itself cannot recognise the shot in this situation.



099058(34)

Tillåten

A permitted weapon malfunction (decision of the referee) permits the firer to complete the group according to the discipline (sport pistol, central fire pistol in rapid fire section) or to repeat it (standard pistol, rapid fire). The execution of this command produces at least one log entry.



99063701(19)

Icke tillgänglig

Non allowable weapon failures normally result in the open group being completed with zero and no repeat being available to the firer. Additionally a log entry is produced.



99063702(16)

Beräkna serie

'Calculate series' completes the handling of weapon malfunctions. Even when several repetitions have had to be shot, on this command the shots are correctly selected and counted according to the rules of the ISSF.



99063703(13)

Övrigt

Frequently used operating elements can be found directly under the Control menu\Other.

Avbryt

Produces in addition to the match total an abort (log entry) in order to mark the current group as invalid.



50(44)

Införa skott '0'

Inserts a shot with the value 0 into the current program. This function is needed if shooting took place without the use of the shot sensor and the target was missed. The system itself cannot recognise the shot in this situation.



099058(34)

Radera tavlan

Clears the shots from the target window without removing them from the score. (see also the setting 'Clear target window after shots')



099062(22)

Radera lista

Clears all entries from the list window, without removing the fired shots from the score.



990630(93)

Convert last sighting shot



09906901(97)

Convert both sighters



09906902(94)

Timer

This commands are used to control the embedded Timer.

Ställ in timer

Sets the Timer to the entered value and displays it in the titlebar



990650(33)

Starta timer

starts the timer



990651(30)

Nollställ timer

Resets the timer to the value set by the Set Timer command



990652(27)

Ta bort timer

Disables the Timer and removes it from the Display



990653(24)

Fix timer values

Here is a collection of fix timer values to configure the timer via Barcode

30s

30s



9906600030(34)

40s

40s



9906600040(04)

50s

50s



9906600050(71)

60s

60s



9906600060(41)

90s

90s



9906600090(48)

300s

5 min



9906600300(97)

1h

1h



9906603600(91)

Target Lifter

Upp



09906916(52)

Ned



09906917(49)

Reference Calibration



09906919(43)

Nästa skottvalör

Every target image has a number of score methods installed, which can be used to evaluate the target. With the command 'Other\Next Primary Score' these different score methods can be scrolled through. These amendments can only be made for



9906421999(45)

free series. It should also be observed that different score methods are not strongly compatible one with another. It is therefore not advisable to change the score method while a program is running.

Nästa decimalskott

Just as for the primary score, so too can the score method for the secondary score be changed.



9906422999(52)

Redigera streckkod



990646(45)

System

Settings and commands that in normal shooting operation must rarely be changed or used. Some of the functions available are also reserved for specific user groups (administrator and Sius staff).

Rapport

With many reports information about past programs can be printed out.

Föreg. serie

The last ten groups can subsequently be loaded once more and considered with the discussion mode. However in a subsequently loaded group no further amendments can be carried out. The shot picture can in this way once again also be created from completed programs and displayed.

1

Load the last program that was shot in order that it can be discussed.



99063800(13)

2

Load the program before last in order that it can be discussed.



99063801(10)

3

Load the third from last program in order that it can be discussed.



99063802(07)

4

Load the fourth from last program in order that it can be discussed.



99063803(04)

5

Load the fifth from last program in order that it can be discussed.



99063804(01)

6

Load the sixth from last program in order that it can be discussed.



99063805(95)

7

Load the seventh from last program in order that it can be discussed.



99063806(92)

8

Load the eighth from last program in order that it can be discussed.



99063807(89)

9

Load the ninth from last program in order that it can be discussed.



99063808(86)

10

Load the tenth from last program in order that it can be discussed.



99063809(83)

Skrivt ut



In the event of a paper jam or other printer problem it can happen that a score sheet does not print out as desired. Finished groups can therefore be repeatedly printed out.

1

Print out the last program again.



09905520(69)

2 <i>Print out the program before last again.</i>	 09905521(66)
3 <i>Print out the third from last program again.</i>	 09905522(63)
4 <i>Print out the fourth from last program again.</i>	 09905523(60)
5 <i>Print out the fifth from last program again.</i>	 09905524(57)
6 <i>Print out the sixth from last program again.</i>	 09905525(54)
7 <i>Print out the seventh from last program again.</i>	 09905526(51)
8 <i>Print out the eighth from last program again.</i>	 09905527(48)
9 <i>Print out the ninth from last program again.</i>	 09905528(45)
Allt <i>Reprint all programs remaining in the log.</i>	 09905529(42)


Skotträknare

Mechanical shot counters:

The optional mechanical shot counter only counts the shots on your own target. It cannot be reset. Demo shots or inserted no scores are not counted. A detailed description of the whole function can be found in the user manual under 'Mechanical shot counters'.



Software shot counters:

The software shot counter counts shots in different categories. Own shots, cross shots, missed shots, demo shots etc. are differentiated and displayed separately. The shot count report is displayed in the list window and provided a printer is connected and switched on, is printed out. The shot counters are connected to the control units. If the settings are reset to factory settings, the shot counts are also reset to zero. The same occurs when the battery has to be changed. With a normal interruption to the power supply, the values are not lost. The software shot counters can also be reset independently of the settings under 'Maintenance\Reports\Shot Counters'.

Visa skotträknaren <i>The current shot numbers are displayed on the screen and on the printer.</i>	 09903608(82)
---	--

Ogiltigt skott

Non-allowable shots (shots during the Stop, Pause or the Show Phase and cross shots) are not only counted, they are kept in the control unit as pending and can be queried at any time. The shots are then shown with the time and if possible with the score. With a warm start or with the command 'Erase' under 'Maintenance\Invalid Shots' the report can be rejected. The shots remain in the log throughout and furthermore can be documented in a log printout.

Visa <i>Rapporten med ogiltiga skott visas i listfönstret.</i>	 990562(06)
Utskrift <i>Rapport som visar ogiltiga skott utskrivit på den ansluta skrivaren. Om skrivaren inte är påslagen förkastas rapporten.</i>	 990564(97)

Log

Events that are of relevance for the duration of a program are filed in the memory (events memory, log). This information is needed to be able to reproduce a program after a power interruption. The CU931 investigates this data at every system start-up. If it is established that the last program to be shot was not correctly ended, then a repetition process is introduced. By means of the log past programs can also be reloaded or a copy can be printed once again. The log is stored in the volatile memory of the control unit, which is buffered with a battery. The data is protected from misinterpretation by a check sum. If the check sum is not correct at system start-up, for example due to a faulty battery, the log is initialised again. The control unit communicates this by a triple beep and a report in the list window. The log is restricted in memory size. In the event of an overload, the oldest events are overwritten by the most recent on a rolling basis. Typically more than ten programs can be stored in the log. The log can also be manually erased under 'Maintenance\Reports\Log'. The format of the printout is described in the user manual.

Allt

All events are printed out in chronological order. The oldest events first, and the most recent events at the end. The printout can be broken off at any time by switching off the printer.



09905500(32)

10

The ten most recent events are printed out in chronological order.



09905501(29)

20

The twenty most recent events are printed out in chronological order.



09905502(26)

50

The fifty most recent events are printed out in chronological order.



09905505(17)

Invertera

All events are printed out in reverse chronological order, the most recent events first, and the oldest events at the end. The printout can be broken off at any time by switching off the printer.



09905509(05)

Inställningar

The performance of the control unit can be adapted to the user's own needs by means of very many different settings. Programs can behave differently according to the properties selected. On the other hand, it is possible for fixed programs to overwrite particular properties. So for example shots are printed out differently in ISSF programs to other programs. It is also possible for programs to select a setting simply as a basic setting, which subsequently (after the program has been switched on) can be changed again by the user. The printout of shots in ISSF disciplines can subsequently be changed again under 'Presentation\Shot\Standard\Print format'.

Presentation

All the settings that affect the images of objects in the wider sense are stored under 'Presentation'. This applies not only to representation on the screen, but also to forms of representation on the printer and other display equipment.

Skott

The directory 'Presentation\Shot' contains settings which alter the appearance of the shots. This affects not only the shot symbol but also the image in the shot window, in the list window and on the printer.

\Skott\Sista skott




In the directory 'Last shot' the settings which influence the depiction of the last represented shot are stored.

\Skott\Sista skott\Symbol

The symbol of a shot can be varied according to appearance, size and background.

\Skott\Sista skott\Symbol\Form

The form of the symbol can be preset individually for the last shot and jointly for all other shots.

Kryss <i>The shot is displayed with a cross.</i>	 09907110(52)
Nummer <i>The shot is displayed with its shot number.</i>	 09907111(49)
Ingen <i>The shot is not displayed.</i>	 09907112(46)
X <i>The shot is displayed with an X.</i>	 09907113(43)
Punkt <i>The shot is displayed with a dot.</i>	 09907114(40)
Fin kyss <i>The shot is displayed with a thin cross.</i>	 09907115(37)
Cirkel <i>The shot is displayed with a cross.</i>	 99071106(17)
Kaliber (Grundinställning) <i>The shot is represented in its true dimensions as a circle, as long as it is no smaller than 5 Pixel. When the dimensions are too small, the image changes automatically to a 'cross'.</i>	 99071107(14)

\Skott\Sista skott\Symbol\Storlek

The image size of the shot can be altered. The size is given in screen dots (Pixels). In the calibre form this setting has no effect.

14 <i>Punkter</i>	 99073300(31)
16 <i>Punkter</i>	 99073301(28)
18 <i>Punkter</i>	 99073302(25)
20 <i>Punkter</i>	 99073303(22)
22 (Grundinställning) <i>Punkter</i>	 99073304(19)
24 <i>Punkter</i>	 99073305(16)
26 <i>Punkter</i>	 99073306(13)
28 <i>Punkter</i>	 99073307(10)

30

Punkter



99073308(07)

32

Punkter



99073309(04)

\Skott\Sista skott\Symbol\Invertera

All symbols are primarily conceived as a white symbol on a dark background. Most targets are black in the centre. The graphics can be inverted. The symbol will then be depicted as a black symbol on a white background.

Av (Grundinställning)

The shot is represented normally.



09907140(59)

På

The shot is represented in inverse colours.



09907141(56)

\Skott\Sista skott>Last Shot Window

In the shot window alongside the shot value, the shot number and a secondary score are indicated. In order to make the representation still clearer, it can be worthwhile to omit the secondary score or the shot number. It is also possible to switch the shot window off altogether.

\Skott\Sista skott>Last Shot Window\Visa

In the shot window alongside the shot value, the shot number and a secondary score are indicated. In order to make the representation still clearer, it can be worthwhile to omit the secondary score or the shot number. It is also possible to switch the shot window off altogether.

Av

The display field for the last shot is faded out.



09907050(38)

Pimär

In the shot window only the primary score is shown.



09907051(35)

SkottNr Valör

In the shot window the shot number and the primary score are shown.



09907052(32)

SkottNr Tiondel (Grundinställning)

In the shot window the shot number, primary and secondary score (100-er score, ISSF tenner ring score) are displayed.



09907053(29)

Timer



09907054(26)

\Skott\Sista skott>Last Shot Window\Deferred Shots

På (Grundinställning)

På



99080701(41)

Av

Av



99080700(44)

\Skott\Sista skott\Visa 10X

De flesta tavlor och figurer har en innerring som förutom den normala valören har ett värde som speciellt bra träff. En träff inom denna ring (innerträff) kan visas på monitorn som en animerad bild (pulsning) i tavelfönstret.

Av

An inner ten (Mouche) hit is displayed as normal.



99074100(56)

På (Grundinställning)

In the event of a hit on the inner ten (Mouche) the control unit shows concentric circles of different sizes one after another several times in the centre of the target.



99074101(53)

\Skott\Standard

In the directory 'Standard' all the settings which affect the depiction of all shots except the last shot are stored.

\Skott\Standard\Symbol

The symbol of a shot can be varied according to appearance, size and background.

\Skott\Standard\Symbol\Form

The form of the symbol can be preset individually for the last shot and jointly for all other shots.

Kryss

The shot is displayed with a cross.



09907030(01)

Nummer

The shot is displayed with its shot number.



09907031(95)

Ingen

The shot is not displayed.



09907032(92)

X

The shot is displayed with an X.



09907033(89)

Punkt

The shot is displayed with a dot.



09907034(86)

Fin kyss

The shot is displayed with a thin cross.



09907035(83)

Cirkel

The shot is displayed with a cross.



99070306(89)

Kaliber (Grundinställning)

The shot is represented in its true dimensions as a circle, as long as it is no smaller than 5 Pixel. When the dimensions are too small, the image changes automatically to a 'cross'.



99070307(86)

\Skott\Standard\Symbol\Storlek

The image size of the shot can be altered. The size is given in screen dots (Pixels). In the calibre form this setting has no effect.

14

Punkter



09907040(68)

16

Punkter



09907041(65)

18 (Grundinställning)

Punkter



09907042(62)

20

Punkter



09907043(59)

22

Punkter



09907044(56)

24

Punkter



09907045(53)

26

Punkter



09907046(50)

28

Punkter



09907047(47)

30

Punkter



09907048(44)

32

Punkter



09907049(41)

\Skott\Standard\Symbol\Invertera

All symbols are primarily conceived as a white symbol on a dark background. Most targets are black in the centre. The graphics can be inverted. The symbol will then be depicted as a black symbol on a white background.

Av

The shot is represented normally.



09907320(04)

På (Grundinställning)

In the event of a hit on the inner ten (Mouche) the control unit shows concentric circles of different sizes one after another several times in the centre of the target.



09907321(01)

\Skott\Standard\Utskriftsformat

The print format dictates the image of a shot on the printout. Print formats are often prescribed directly by programs. So the printout at an international contest is laid out differently to that of a compulsory confederation practice in Switzerland.

\Skott\Standard\Utskriftsformat\Use Always

På



99073199(43)

Av (Grundinställning)



99073198(46)

Grundinställning (Grundinställning)

The printer prints the shot with shot number, direction arrow, primary and secondary score.



99073100(49)

Xy

On the printer the primary and secondary score and the XY coordinates are printed out.



99073101(46)

t x/y

As well as the primary score, the time of the shot and its coordinates are displayed.



99073109(22)

Tid

In the 'Time' format the time difference from the first shot of the group is always depicted.



99073108(25)

Debug

The debug format is only intended for test purposes. It supplies all the values which have been measured by the LON electronic measuring system. As well as register values the recorded temperature and other information is listed.



99073102(43)

\Skott\Standard\Visa format

Grundinställning (Grundinställning)

The shot is displayed with shot number, direction arrow, primary and secondary score in the list window.



99070800(62)

Xy

In the list window the primary and secondary scores and the XY coordinates are displayed.



99070801(59)

t x/y

As well as the primary score, the time of the shot and its coordinates are displayed.



99070809(35)

Tid

Display format 'Time' the time gap to the first shot of the current group will also be displayed.



99070808(38)

Debug

The debug format is only intended for test purposes. It supplies all the values which have been measured by the LON electronic measuring system. As well as register values the recorded temperature amongst others is listed.



99070802(56)

\Skott\Standard\Tiondel

The secondary score can be always switched off.

Av

The secondary score is switched off.



09907120(22)

På (Grundinställning)

The secondary score is switched on.



09907121(19)

\Skott\Standard\Radera tavlan efter skott

In test and single groups the setting 'Clear target window after shots' enables the target window to be regularly cleared and so to remain clear. Thereby the shots are counted comprehensively by group. But this is only in test and single groups. In series groups all shots are shown one after another without shots being cleared in between. Consequently with the setting 10 in the following program: 'T2 S4 S4 S4' the target window is cleared after 2 shots

(because the test group has come to an end and the shoot will continue with a single group). Additionally the same action is carried out in the last 'S4' group after the second shot (because 10 shots have been used in the single groups).

0

Rensar tavelfönstret efter 20 skott.



99078600(39)

5

Rensar tavelfönstret efter 5 skott.



99078605(24)

10 (Grundinställning)

Rensar tavelfönstret efter 10 skott.



99078610(09)

20

Rensar tavelfönstret efter 20 skott.



99078620(76)

\Skott\Kors skott

I katalogen 'Korsskott' finns inställningar som påverkar visning av korsskott (skott från annan skytt på sin egen tavla).

\Skott\Kors skott\Visa

Korsskott visas med en symbol i tavelfönstrets nedre högra del. Symbolen visas i 7 min. Om det sista korsskottet är äldre än 7 min. släcks symbolen. I tillägg kan det i listfönstret visas ett meddelande om korsskottet.

Av (Grundinställning)

The showing of cross shots is suppressed in the list window. The first cross shot is displayed with a symbol in the target window in the bottom right corner.



09907060(08)

På

Cross shots are displayed in the list window with the entry 'cross shot'.



09907061(05)

\Skott\Kors skott\Utskrift

Korsskott kan både visas i tavelfönstret och skrivas ut.

Av (Grundinställning)

Cross shots are not displayed on the printer. In particular if printing is done onto pre-printed sheets (federal programs, field shooting) cross shots may not influence the formatting.



09907170(66)

På

A cross shot is output on the printer.



09907171(63)

\Skott\Ogiltigt skott

I katalogen '\Ogiltiga skott' finns inställningar som påverkar visning av skott efter eld upphör; under stopp-, paus- eller visningsfasen.

\Skott\Ogiltigt skott\Visa

Invalid shots can be displayed in the list window.

Av

The showing of non-allowable shots is suppressed in the list window.



99073400(22)

På (Grundinställning)

Invalid shots are indicated in the list window with 'Invalid Shot'.



99073401(19)

\Skott\Ogiltigt skott\Utskrift

Invalid shots can be printed.

Av

Invalid shots are not printed.



99073500(13)

På (Grundinställning)

An non-allowable shot is printed out on the score sheet as 'non-allowable shot'.



99073501(10)

\Skott\Bästa skott

In serial groups the best shot (low shot) at the end can be shown once more and printed out in round brackets together with the shot number.

Av

The display of the best low shot is suppressed.



99079700(37)

På (Grundinställning)

The best low shot is displayed in series groups.



99079701(34)

Skriver

In the directory 'Presentation\Printing' all the settings which control the printer can be changed.

\Skriver\Kolumnkonfiguration

För matris skrivaren D93 finns papper som är perforerat i mitten. Med kolumnkonfiguration kan programmet ställas in så att utskrift sker på två kolumner. Det perforerade pappret kan därefter delas på mitten. Märk dock att vissa utskrifter (bl.a. ISSF discipliner) inte kan placeras på halva pappret. Informationen slutar efter 19 tecken. Detta kan medföra att information saknas.

\Skriver\Kolumnkonfiguration\Use Always

På



99071399(11)

Av (Grundinställning)



99071398(14)

M

Utskrift sker vänsterjusterat. Hela pappersbredden är tillgänglig för utskrift.



09907130(89)

Höger

Utskrift sker högerjusterat. Bara halva pappersbredden är tillgänglig för utskrift.



09907131(86)

Dubbel (Grundinställning)

Utskrift sker två gånger efter varandra. Endast halva pappersbredden är tillgänglig för utskrift.



09907132(83)

\Skriver\Skriv ut skjutprotokoll

The printing out of shots on the printer during a program can always be switched on and off with 'Print records'.

Av

The records are not printed.



99076300(52)

På (Grundinställning)

The records are printed.



99076301(49)

\Skriver\Tiondel

Although the secondary score is shown, the printout of the secondary score can be suppressed.

Av (Grundinställning)

The secondary score is not printed.



09907250(20)

På

The secondary score is printed.



09907251(17)

\Skriver\Provskott

Test shots are usually printed out just like all other shots. However, in order that pre-printed score sheets are not overwritten with test shots, it is possible to block the printing out of test shots.

Av

Test shots are displayed only on the screen.



09907160(96)

På (Grundinställning)

Test shots are displayed on the printer. The exception to this is shooting programs consisting of only one test group. These shots are never printed. This was done so that pre-prepared score sheets could be sued correctly.



09907161(93)

\Skriver\Delsumma

The shots of every group are counted together and the result is displayed in the list window and on the printer. It is possible to suppress these totals on the printout.

Av

Subtotals or group totals are not printed.



09907210(43)

På (Grundinställning)

Subtotals or group totals are printed.



09907211(40)

\Skriver\Print Overtime

Av



99080600(53)

På (Grundinställning)



99080601(50)

\Skriver\Print number of Innertens

Av (Grundinställning)



99081300(87)

















På



99081301(84)

\Skriver\Antal tomrader

After a program the printer should advance the paper so far that with continuous paper it can be torn off correctly on the cutting edge of the printer. With pre-printed score sheets it can happen that this paper feed must be altered. With 'Number of Empty Lines' it is possible to specify how many empty lines (paper feed) should be printed after a program.

0	
<i>Tomma rader</i>	99074000(65)
1	
<i>Tomma rader</i>	99074001(62)
2	
<i>Tomma rader</i>	99074002(59)
3	
<i>Tomma rader</i>	99074003(56)
4	
<i>Tomma rader</i>	99074004(53)
5	
<i>Tomma rader</i>	99074005(50)
6	
<i>Tomma rader</i>	99074006(47)
7	
<i>Tomma rader</i>	99074007(44)
8	
<i>Tomma rader</i>	99074008(41)
9	
<i>Tomma rader</i>	99074009(38)
10	
<i>Tomma rader</i>	99074010(35)
11 (Grundinställning)	
<i>Tomma rader</i>	99074011(32)
12	
<i>Tomma rader</i>	99074012(29)
13	
<i>Tomma rader</i>	99074013(26)
14	
<i>Tomma rader</i>	99074014(23)
Antal tomrader	
<i>After a program the printer should advance the paper so far that with continuous paper it can be torn off correctly on the cutting edge of the printer. With pre-printed score sheets it can happen that this paper feed must be altered. With 'Number of Empty Lines' it is possible to specify how many empty lines (paper feed) should be printed after a program.</i>	990645(48)

Skjutning

With the settings '\Presentation\ Program' or '\Presentation\ Group' the form of depiction of expressions and readouts in the list window can be changed. But many programs have their own fixed format. These settings should only be changed in consultation with Sius AG.

\Skjutning\Utskrift

\Skjutning\Utskrift\Sidhuvud

Tom



99075100(63)

Name (Grundinställning)



99075105(48)

Kort



99075101(60)

Line feed

Omgången blir separerad med hjälp av en tomrad.



99075102(57)

\Skjutning\Programed Timers

This settings determines if the programmed Timers for ISSF-Disziplines should be used or not.

Av (Grundinställning)

Disables the programmed Timers fo ISSF-Disziplines



99080800(35)

På

Activates the programmed Timers for ISSF-Disziplines



99080801(32)

Omgång

With the settings '\Presentation\ Program' or '\Presentation\ Group' the form of depiction of expressions and readouts in the list window can be changed. But many programs have their own fixed format. These settings should only be changed in consultation with Sius AG.

\Omgång\Utskrift

\Omgång\Utskrift\Sidfot

Total (Grundinställning)



99075407(15)

Total with SeqNr



99075412(97)

Grupp

The directory '\Presentation\Group' contains settings which influence the behaviour of individual groups.

\Grupp\Nollställa skottnummer

If this option is selected, the shots within this group are always numbered beginning with a 1. Otherwise the shots within the whole practice are continuously numbered. Test shots are excluded from this.

Av (Grundinställning)

The shot numbers are continuously numbered in a program.



99073700(92)

På

The numbering of the shots begins again with '1' with every group.



\Grupp\Delsumma

The group totals in a program can be displayed in the program progress window. For completed groups the fire type and the number of shots (e.g. E2 S4) are replaced by the respective subtotals.

Av (Grundinställning)

The end of program window shows the types of fire and the active group.



På

In the program progress window the fire type of the concluded groups is replaced by the subtotal of the current group.



Övrigt

In the directory 'Presentation\Other' can be found the settings which cannot be assigned to another group.

\Övrigt\Manöverenhet

Settings affecting the basic layout of the image are stored under 'Screen'.

\Övrigt\Manöverenhet\Layout

Bilden på kontrollenheten kan justeras för att uppfylla individuella krav så långt som möjligt.

Klassisk (Grundinställning)

Den klassiska presentationen uppfyller de flesta skyttars behov.



Stopp vänster

När monitorn är placerad på skyttens högra sida kan det bra att skytten utan stora huvudrörelser kan se statusindikeringen. För detta ändamål har statusfönstret i layouten 'Stopp vänster' flyttats. I layouten 'Stopp vänster' är statusfönstret borttaget ur platsbyråsyn. Information som visas i statusfönstret blir inte längre synligt eller visas i listfönstret.



Final

Om skyttarnas monitorer skall vara synlig för åskådarna kan tavelfönstret göras större med 'final' layouten. I finallayouten syns inte status-, tävlingsprogram- och menyvalfönstret.



AZT

Om skyttarnas monitorer skall vara synlig för åskådarna kan tavelfönstret göras större med 'final' layouten. I finallayouten syns inte status-, tävlingsprogram- och menyvalfönstret.



\Övrigt\Manöverenhet\Funktions tangenter

The window with the menu keys is displayed on the LCD of the control unit and at the lower edge of the screen. In portable devices (handheld) the function key window should not be switched off because this device has no LCD.

Av

The bar with the function keys is concealed. Details of the keypad mode are only available on the LCD of the control unit.



På (Grundinställning)

The bar with the function keys is also overlaid on the screen.



99074401(26)

\Övrigt\Manöverenhet>Status blinkar

In order that the fire's attention can better be drawn to the screen, the most important status information (stop, offline) flashes in the status window. This effect, which can also be distracting, can be turned off with this setting.

Av (Grundinställning)

The status window will indicate no status by flashing.



99078800(21)

På

The most important information (stop, offline, show) is displayed flashing.



99078801(18)

\Övrigt\Manöverenhet\Övningsfönster

The display of the program progress window can be suppressed.

Av

The end of program window is not displayed.



99074300(38)

På (Grundinställning)

The end of program window is displayed.



99074301(35)

\Övrigt\Manöverenhet\Large font in Listwindow

Anger teckensnitt för text i listfönstret.

Av (Grundinställning)

Normalt teckensnitt kommer att användas i listfönstret.



99080200(89)

På

Stort teckensnitt kommer att användas i listfönstret.



99080201(86)

\Övrigt\Meddelande

Under 'Messages' the way the control unit handles messages can be configured.

\Övrigt\Meddelande\Visa meddelanden

The control unit displays various texts as reports in the list window. Many of these reports are laid out in such a way that they are also displayed on the LCD near the keyboard. With this setting these outputs can be limited.

Av

Reports are no longer displayed.



99073800(83)

På monitor

Only reports that are displayed in the list window are shown. The readouts on the LCD are suppressed. This setting is useful when the display screen is to be set up directly next to the control unit. In this situation readouts on the LCD can then be suppressed.



99073801(80)

På LCD

Only reports that are displayed in the LCD are shown. The readouts in the list window of the screen are suppressed. This setting is useful when the control unit is to be set up some distance away from the display screen. Usage is then mainly controlled via the LCD.



99073802(77)

På båda (Grundinställning)

All reports are displayed both on the LCD and in the list window of the screen.



99073803(74)

\Övrigt\Meddelande\Info tavelmatning

The S10, the S25/50, the S101 and other targets have a materials handling (paper or rubber band feed). If the motors stall, the material runs out or the band jams, then the target reports a band feed error to the control unit. It is essential to correct this error as missing band feed can lead to incorrect measurements in the detection system. However, the display of the error message can be suppressed. This only serves a useful purpose when no targets with band feed have been installed or for test purposes, when no band is available, but the unit nonetheless needs to run in simulation mode.

Av

Reported line feed errors are suppressed.



99073000(58)

På monitor (Grundinställning)

Reported line feed errors are only displayed in the list window of the screen.



99073001(55)

På skrivare

Reported line feed errors are only printed.



99073002(52)

På båda

Reported line feed errors are shown in the list window and printed.



99073003(49)

\Övrigt\Visa figurnamn

The target description and the names of the active score methods are displayed in the upper left corner of the target window.

Av

The target description and the score information are suppressed.



99074200(47)

På (Grundinställning)

In the target window the target name and the score information are shown.



99074201(44)

\Övrigt\Kaliber

The calibre is displayed together with the measurement in the upper left corner of the target window. If the calibre is written inside round brackets, then in addition this means that the score is calculated as centre score. The advantage of score methods with central score is that they are independent of the calibre.

Av

Information om tolkning döljs.



99078300(66)

På (Grundinställning)

Information om tolkning visas.



99078301(63)

\Övrigt\Indikera

There are situations in which the firer should not be informed about the shot which has been fired. If the screen is switched off, then the shot situation is not relayed. No entry is made in the list window and no printout is produced. Only the shot number is displayed in the shot window.

Av

All displays (graphics window, list window, shot window and printer) are suppressed. The shot information is visible only on an associated PC and in the log. The function is used when statistical measurements need to be made and the firer must not be influenced by the result.



09907260(87)

På (Grundinställning)

Images are no longer suppressed.



09907261(84)

Parametrar

Parameters are optional functions that can be turned on if desired. Parameters can be set in many ways. There are parameters that affect the image, parameters that calculate statistical values, and many more. Parameters must be switched on before a particular program is input.

MTP

The MPI (mean point of impact) calculates the mean point of impact of the last five shots and indicates this spot as coordinates in the statistics window and as a small square in the target window. The number of shots that were included in the calculation of the MPI can also optionally be displayed in the statistics window.

\MTP\Text

The text readout in the statistics window can be suppressed.

Av

Only the small square on the site of the mean hit point is indicated. The text readout in the statistics window is suppressed.



99079500(55)

På (Grundinställning)

In addition to the graphic square in the statistics window a text with direction and place details is displayed via the MPI.



99079501(52)

\MTP\MTP

The MPI can be turned on and off as a whole (graphics and text).

Av

The MPI is not calculated.



99078100(84)

På (Grundinställning)

The MPI is calculated.



99078101(81)

Simulera resultattavla

The SCB parameter (scoreboard) simulates the details of a scoreboard in the statistics window.

Av

The SCB is not copied.



99080100(01)

På (Grundinställning)

The scoreboard is replicated in the statistics window.



99080101(95)

Divisor

The divider is a score method which is used above all in Germany. It shows the distance of the point of entry of a shot from the centre of the target in 1/10 millimetre. The goal of a firer is to achieve the lowest possible number of dividers. The divider exists as a parameter and is displayed in the statistics window. In addition the divider values of all shots in one program are added up. The divider can be chosen as a score method in free series. In this way it is possible to select the divider as a primary or secondary score.

Av (Grundinställning)

The divider parameter in the statistics window is turned off.



99079300(73)

På

The divider parameter in the statistics window is turned on.



99079301(70)

Fi

The parameter Fi indicates the distance between the shots which are furthest apart in a group in the statistics window.

Av (Grundinställning)

The parameter Fi is not calculated.



99079100(91)

På

The parameter Fi is calculated.



99079101(88)

FiFi

The parameter FiFi indicates the distance between the shots which are furthest apart in an entire program in the statistics window. With very large numbers of shots, this parameter is very calculation intensive and the operating rate of the control unit can become noticeably slower.

Av (Grundinställning)

The parameter FiFi is not calculated.



99079200(82)

På

The parameter FiFi is calculated.



99079201(79)

Skidskytte

Av (Grundinställning)



99079000(03)

På



99079001(97)

Spridning

The distance between those shots which lie furthest apart horizontally is calculated and displayed in the statistics window. The distance between those shots which lie furthest apart vertically is similarly calculated and displayed.

Av (Grundinställning)

The X and Y ranges are not calculated.



99080000(10)

På

The X and Y ranges are calculated.



99080001(07)

Språk

The control unit supports several languages. The language of the user guidance can be individually adjusted.

English (Grundinställning)

Menyspråket är på engelska.



99070200(19)

Deutsch

Menyspråket är på tyska.



99070201(16)

Språk

The control unit supports several languages. The language of the user guidance can be individually adjusted.

English (Grundinställning)

Menyspråket är på engelska.



99070200(19)

Deutsch

Menyspråket är på tyska.



99070201(16)

<p>Français <i>Menyspråket är på franska.</i></p>	 99070202(13)
<p>Español <i>Menyspråket är på spanska.</i></p>	 99070207(95)
<p>Dansk <i>Menyspråket är på danska.</i></p>	 99070204(07)
<p>Norsk <i>Menyspråket är på norska.</i></p>	 99070205(04)
<p>Svenska <i>Menyspråket är på svenska.</i></p>	 99070206(01)
<p>Italiano <i>Menyspråket är på italienska.</i></p>	 99070203(10)
<p>Russian <i>Menyspråket är på ryska.</i></p>	 99070208(92)

Tid

The clock time that is shown in the title bar can be set and the form of the representation can be changed.

Justera tid

Tiden kan ställas in på varje kontrollenhet. När fler kontrollenheter är kopplade till ett LON-nätverk, blir en ändring av tiden överförd till alla kontrollenheterna. Helst bör tiden alltid ställas in på kontrollenheten med lägst sub-nät nummer. Eftersom kontrollenheten med lägst sub-nät nummer är automatiskt ansvarig för att övriga kontrollenheter synkroniseras. Korrekt tid på alla kontrollenheter är nödvändigt för att rätt skjutresultat skall erhållas vid skottutvärdering.

<p>År- <i>Ett år tas bort från visat år.</i></p>	 99063100(76)
<p>År+ <i>Ett år läggs till visat år.</i></p>	 99063101(73)
<p>Månad- <i>En månad tas bort från månaden som visas.</i></p>	 99063102(70)
<p>Månad+ <i>En månad läggs till månaden som visas.</i></p>	 99063103(67)
<p>Dag- <i>En dag tas bort från visat datum.</i></p>	 99063104(64)
<p>Dag+ <i>En dag läggs till det datum som visas.</i></p>	 99063105(61)
<p>Timme- <i>En timme tas bort från timmen som visas.</i></p>	 99063106(58)
<p>Timme+ <i>En timme läggs till timmen som visas.</i></p>	 99063107(55)

Minut-

En minut tas bort från minuten som visas.



99063108(52)

Minut+

En minut läggs till minuten som visas.



99063109(49)

Sekund 0-ställ

Vald minut startar från noll.



99063110(46)

Datumformat

The date format can be adjusted according to the circumstances of the country.

Kortversion

*The date in short format looks for example like this:
27.09 17:32*



99076900(95)

Europeisk (Grundinställning)

The date in 'European' format looks for example like this: 27.09.2004 17:32



99076901(92)

Europeisk+sekunder

The date in 'European plus seconds' format looks for example like this: 27.09.2004 17:32:15



99076902(89)

US

*The date in 'US' format looks for example like this:
09/27/2004 17:32*



99076903(86)

US+sekunder

The date in 'US plus seconds' format looks for example like this: 09/27/2004 17:32:15



99076904(83)

Övrigt

The directory 'Other\Settings' contains all settings that cannot be unequivocally classified in any other category.

Start

Start settings concern the system startup (switching on) on the one hand, and variations in program start settings on the other hand.

\Start\Möjliggöra Repetering

After a program has been shot the control menu changes automatically. When the status changes to 'Stop', a new button 'Repeat' appears. There are occasions when a firer may shoot a program only once. In this case the permission for 'Repeat' must be denied.

Av

The function 'Repeat' is barred.



99077100(77)

På (Grundinställning)

The function 'Repeat' is permitted.



99077101(74)

\Start\återställa fria serier

Free series are represented in the practice progress window with three open groups. The method of operation of the free series is described in the user manual. The start setting defines which of the three groups should be started.

Prov (Grundinställning)

Every free series starts with the test group. In the practice progress window the test group T is on a white background.



99079400(64)

Enkel

Alternatively a free series can also be started directly with the open single group S-.



99079401(61)

\Start\Automatisk uppstart

If a program has been selected this can be saved as a start-up program. The control unit will then in future automatically load the start-up program as long as no rebuild has been launched. User programs cannot be consigned as start-up programs. If the start-up program is saved after a user program has been loaded, in future the control unit will start up with a free series but with the right target.

Rensa

If an autostart program has been saved, then this setting is erased. In future the control unit will not automatically select any program when turned on.



99079800000(58)

Spara

The program that has currently been chosen will load automatically in future when the control unit is turned on.



990798065535(72)

\Start\SC-Programs

\Start\SC-Programs\Single Execution

Av (Grundinställning)



99081100(08)

På



99081101(05)

\Start\Scale Factor

Reset



9908101000(58)

Scale Factor (600)



9908100600(94)

Set Scale Factor



99064700(29)

\Start\Target Alternative

Setting for special variants of programs.

Grundinställning

Standard procedure



99080900(26)

Höger

Used for Moving Mosse Exercise starting on right side instead of left side.



99080901(23)

\Start\Automatisk nollställning

Under certain conditions the resources of the control unit can become limited. This affects mainly the on hand working memory, its fragmentation and the working speed of the control unit. If certain limits are exceeded, the control unit can restart by itself and thus fix the resource shortage. This only occurs when the status of the control unit has been on 'Stop' for a long time or if the screen saver is activated. In these situations the control unit starts up again automatically.

Av

The control unit may not be restarted automatically.



99078400(57)

På (Grundinställning)

The control unit may restart automatically under certain conditions.



99078401(54)

Filter

With many filters the menu can be shortened to those items which the user finds most essential. For instance if a certain distance is selected, all other distances and the programs associated with them can be suppressed. Thus so-called filter dimensions are created (user groups, distance, category etc.). A filter dimension contains several filter characteristics. The dimension 'User Group' comprises the characteristics Standard, Advanced, Administrator and Sius. A comprehensive description of the filter options can be found in the user manual.

\Filter\Distans

Alla tavlor och program är först och främst organiserade efter avstånd. Tavlor som används bara på ett visst avstånd blir grupperade därefter. Filtret för avstånd är det effektivaste filtret.

\Filter\Distans\Övrigt

Tavlor och program som inte används för ett speciellt avstånd.

Av (Grundinställning)

The filter characteristic is deactivated.



990635030400(49)

På

The filter characteristic is activated.



990635030401(46)

\Filter\Distans\10m

Tavlor och program som används för 10 m avstånd.

Av (Grundinställning)

The filter characteristic is deactivated.



990635030000(85)

På

The filter characteristic is activated.



990635030001(82)

\Filter\Distans\25m

Tavlor och program som används för 25 m avstånd.

Av (Grundinställning)

The filter characteristic is deactivated.



990635030100(76)

På

The filter characteristic is activated.



990635030101(73)

\Filter\Distans\50m

Tavlor och program som används för 50 m avstånd.

Av (Grundinställning)

The filter characteristic is deactivated.



990635030200(67)

På

The filter characteristic is activated.



990635030201(64)

\Filter\Distans\300m

Tavlor och program som används för 300 m avstånd.

Av (Grundinställning)

The filter characteristic is deactivated.



990635030300(58)

På

The filter characteristic is activated.



990635030301(55)

Reset

Switch off all settings of this filter dimension and thereby deactivate filtering in this dimension.



990635039902(61)

\Filter\Kategorie

Program och tavlor är i andra hand grupperat efter kategori. Detta med tanke på att program eller tavlor kan tillordnas den mest utbredda kategorin. Det betyder som exempel att pistoltavlorna för 50m finns under ISSF även om de utnyttjas frekvent i Schweiz. Men ISSF är en mer generell kategori än 'Schweiz' därför är tavlorna placerade under kategorin ISSF.

\Filter\Kategorie\Övrigt

Program och tavlor som inte kan placeras i någon annan kategori.

Av (Grundinställning)

The filter characteristic is deactivated.



990635010800(67)

På

The filter characteristic is activated.



990635010801(64)

\Filter\Kategorie\ISSF

Tavlor och program som tillhör ISSF reglemente.

Av (Grundinställning)

The filter characteristic is deactivated.



990635010000(42)

På

The filter characteristic is activated.



990635010001(39)

\Filter\Kategorie\CISM

Tavlor och program som tillhör CISM reglemente.

Av (Grundinställning)

The filter characteristic is deactivated.



990635010100(33)

På

The filter characteristic is activated.



990635010101(30)

\Filter\Kategorie\Jakt

Tavlor och program som används enbart som jakttavlor eller jaktprogram.

Av (Grundinställning)

The filter characteristic is deactivated.



990635010400(06)

På

The filter characteristic is activated.



990635010401(03)

\Filter\Kategorie\Belgium

Targets and programs that are used almost exclusively in Belgium..

Av (Grundinställning)
The filter characteristic is deactivated.



990635011000(49)

På
The filter characteristic is activated.



990635011001(46)

\Filter\Kategorie\Sui

Program och tavlor som används mestadels i Schweiz.

Av (Grundinställning)
The filter characteristic is deactivated.



990635010200(24)

På
The filter characteristic is activated.



990635010201(21)

\Filter\Kategorie\Skandinavien

Program och tavlor som används mestadels i Skandinavien.

Av (Grundinställning)
The filter characteristic is deactivated.



990635010300(15)

På
The filter characteristic is activated.



990635010301(12)

\Filter\Kategorie\Militär

Kategorin Militär bildar en underkategori i somliga regioner. Till exempel i Skandinavien är civil och militära tävlingar gemensamma. I kategorin 'Militär' är tavlor och program som är endast för civil sport exkluderade.

Av (Grundinställning)
The filter characteristic is deactivated.



990635010900(58)

På
The filter characteristic is activated.



990635010901(55)

Reset
Switch off all settings of this filter dimension and thereby deactivate filtering in this dimension.



990635019902(18)

\Filter\Vapen

Vissa vapentyper används endast på vissa avstånd. T.ex. luftvapen används endast på 10m och 25m och pistoler används inte på 300m. I en anläggning som bara används för pistol kan man dölja alla gevärstavlor och program med hjälp av filter.

\Filter\Vapen\Övrigt

All targets and programs that cannot be assigned to another weapon type.

Av (Grundinställning)
The filter characteristic is deactivated.



990635050400(92)

På
The filter characteristic is activated.



990635050401(89)

\Filter\Vapen\Gevär

Targets and programs that are shot exclusively with rifles.

Av (Grundinställning)
The filter characteristic is deactivated.



990635050000(31)

På
The filter characteristic is activated.



990635050001(28)

\Filter\Vapen\Pistol

Targets and programs that are shot exclusively with pistols.

Av (Grundinställning)
The filter characteristic is deactivated.



990635050100(22)

På
The filter characteristic is activated.



990635050101(19)

\Filter\Vapen\Luftgevär

Targets and programs that are shot exclusively with air rifles.

Av (Grundinställning)
The filter characteristic is deactivated.



990635050200(13)

På
The filter characteristic is activated.



990635050201(10)

\Filter\Vapen\Luftpistol

Targets and programs that are shot exclusively with air pistols.

Av (Grundinställning)
The filter characteristic is deactivated.



990635050300(04)

På
The filter characteristic is activated.



990635050301(01)

Reset
Switch off all settings of this filter dimension and thereby deactivate filtering in this dimension.



990635059902(07)

\Filter\Användar grupp

Med filtret 'Användare Grupp' kan ett förenklat användartillstånd bildas. Olika nivåer av tillstånd kan tilldelas olika användargrupper.

\Filter\Användar grupp\Standard

A standard user can use only the normal shooting operation. He is forbidden to change settings or even to configure hardware components.

Av (Grundinställning)
The filter characteristic is deactivated.



990635040000(58)

På
The filter characteristic is activated.



990635040001(55)

\Filter\Användar grupp\Avancerad

An 'Advanced' user can amend the major settings and print out supplementary reports.

Av (Grundinställning)
The filter characteristic is deactivated.



990635040100(49)

På
The filter characteristic is activated.



990635040101(46)

\Filter\Användar grupp\Administratör

Maintenance tasks and hardware settings can only be amended if at least one administrator is configured.

Av (Grundinställning)
The filter characteristic is deactivated.



990635040200(40)

På
The filter characteristic is activated.



990635040201(37)

\Filter\Användar grupp\Sius

Special functions are reserved for Sius staff.

Av (Grundinställning)
The filter characteristic is deactivated.



990635040300(31)

På
The filter characteristic is activated.



990635040301(28)

Reset
Switch off all settings of this filter dimension and thereby deactivate filtering in this dimension.



990635049902(34)

\Filter\Funktion

Kontrollenhetens betjäningssfunktioner är indelade i funktionsgrupper. Med hjälp av filtrering för varje funktionsgrupp kan oönskade områden döljas.

\Filter\Funktion\Övrigt

Functions which cannot be assigned to another function group.

Av (Grundinställning)
The filter characteristic is deactivated.



990635020200(94)

På
The filter characteristic is activated.



990635020201(91)

\Filter\Funktion\Logga in

Functions which are needed for the identification of firer.

Av (Grundinställning)
The filter characteristic is deactivated.



990635020000(15)

På
The filter characteristic is activated.



990635020001(12)

\Filter\Funktion\Fria serier

Functions which are needed only in free series.

Av (Grundinställning)
The filter characteristic is deactivated.



990635020100(06)

På

The filter characteristic is activated.



990635020101(03)

\Filter\Funktion\Program

Functions which are needed only in free series.

Av (Grundinställning)

The filter characteristic is deactivated.



990635020300(85)

På

The filter characteristic is activated.



990635020301(82)

\Filter\Funktion\Skytt nummer

When only the function 'Firer number' is permitted, but not the function 'Report', then the firer number can be retrieved but the other information about position, weapon, sight etc. remains invisible.

Av (Grundinställning)

The filter characteristic is deactivated.



990635020400(76)

På

The filter characteristic is activated.



990635020401(73)

Reset

Switch off all settings of this filter dimension and thereby deactivate filtering in this dimension.



990635029902(88)

\Filter\Mode

I motsats till andra inställningar filtrerar icke Mode någon menyfunktion. I tidigare Sius-system var det helt nödvändigt att använda Mode-inställningen för att rätt detekteringssystem skulle bli igenkänt. I kontrollenheten behövs inte denna information längre. Men som tidigare kan Mode-inställningen användas som förregling. Varje tavla och program är tilldelad en Mode. En tävling kan ställas in bara om filter Moden är inställt på 'Av' eller när program Moden stämmer överens med den inställda Moden. Denna förregling fungerar även när tavlan eller programmet läses in från en streckodläsare. Väljs t.ex. moden '300m' kan inga jakttavlor väljas. Kontrollenheten avger en passande felmeddelande i listfönstret.

Av (Grundinställning)

All the programs can be selected.



99071899(63)

Luftvapen

Shooting mode for air pressure weapons and programs that are shot over a 10 metre distance. (Mode 2)



99071802(63)

25m

Mode for 25 metre and 50 metre small calibre and large calibre pistols as well as for small calibre rifles. (Mode 3)



99071803(60)

50m

Targets and programs that are shot from 50 metres. This concerns large and small calibre pistols and small calibre rifles as well as special Swiss groups (Morgarten). (Mode 4)



99071804(57)

300m

Targets and programs for 300 metre disciplines (Mode 0)



99071800(69)

<p>Jakt Hunting targets and hunting programs (Mode 1)</p>	 99071801(66)
<p>Skandinavien Scandinavian targets (Denmark, Norway, Sweden) (Mode 11)</p>	 99071811(36)
<p>Rörligt mål Targets and programs for the running target for 10 and 50 metres (Mode 12)</p>	 99071812(33)
<p>Skidskytte Targets and programs for biathlon disciplines (Mode 13)</p>	 99071813(30)

Kaliber

With most targets and programs a certain calibre is implicitly assumed. With targets that are well known to be fired at with different weapons types and thus with different calibres, the most common selection options are already available. The calibre is used on the one hand for the image in the graphics window, and on the other hand certain score methods require the calibre to calculate the score. In the modern ISSF disciplines the score is calculated by means of the shot hole centre (centre score). The calibre is fixed (e.g. air pressure disciplines 4.5mm.) Even when a larger calibre is employed, these disciplines are evaluated with the calibre that was fixed. Such score methods are identified in the target window with the note 'centre score'. With older targets that are evaluated with edge score, the selected calibre has an effect on the score. Changes to this setting are therefore logged.

\Kaliber\Use Always

<p>På</p>	 99079699(40)
<p>Av (Grundinställning)</p>	 99079698(43)
<p>Av Alla discipliner som inte tolkas för en viss bestämd kaliber blir bedömd efter skotthålscentrum.</p>	 990796000000(26)
<p>450 Alla discipliner som inte tolkas för en viss bestämd kaliber, eller med hjälp av skotthålscentrum blir bedömd med 4,5mm kaliber.</p>	 990796000450(34)
<p>560 Alla discipliner som inte tolkas för en viss bestämd kaliber, eller med hjälp av skotthålscentrum blir bedömd med 5,6mm kaliber.</p>	 990796000560(92)
<p>800 Alla discipliner som inte tolkas för en viss bestämd kaliber, eller med hjälp av skotthålscentrum blir bedömd med 8mm kaliber.</p>	 990796000800(51)
<p>900 Alla discipliner som inte tolkas för en viss bestämd kaliber, eller med hjälp av skotthålscentrum blir bedömd med 9mm kaliber.</p>	 990796000900(42)

965

Alla discipliner som inte tolkas för en viss bestämd kaliber, eller med hjälp av skotthålscentrum blir bedömd med 9,65mm kaliber.



990796000965(41)

1158



990796001158(44)

1270



990796001270(96)

Control Mode

The control mode regulates various stages of the remote control. The control unit is configured so that for example it can be controlled remotely by Siusdata ®.

Lokal (Grundinställning)

All functions can be carried out via the keyboard or the barcode reader.



09907790(49)

Utbildnings kontroll

*In certain ISSF disciplines (e.g. 3*40 rifle shoot) the control unit goes into a paused state. This state can be released with a command from SiusData ®. In this way a change of position can be ordered for a whole score.*



09907791(46)

Avlägsna

If the control unit is totally remotely controlled, entries via the keyboard or the barcode reader are barred.



09907792(43)

Demo

The demo mode is displayed in the status window (small font). In demo mode shots can be created via the insert key ('Ins'). The control unit requests the connected target to create a shot at a chance coordinate and to send this back to the control unit. The demo shot implicitly tests both the connected target and the communication. Demo mode is switched off every time at startup.

Av (Grundinställning)

Turns off the demo mode.



09907000(91)

På

Selects demo mode.



09907001(88)

Activate remote barcode

This command sets the CU in the remote barcode mode. While activated all Barcodes from the connected Barcodereader will be sent to the specified Lane. To change the selected lane press the specified keys on the keyboard, to exit remotebarcode mode press escape. The configuration of the key-lane selection can be downloaded from siusdata, default setting is that with the numeric keys 1-9,0 the different lanes on a normal 10 CU desk can be selected.



099067(07)

Demonstration Mode



099068(04)

Kontroll inställningar

It is possible to store one's own setting configurations in the permanent memory of a control unit. These customer settings will not be lost even with a change of battery. Even during a 'cold start' these settings will not be overwritten by the factory settings. So it can be guaranteed that your own settings can also be selected as standard. The settings will only be lost if a new software version is loaded. It is possible to save these settings as a file on a computer and with SiusData to load them via the LON network onto all connected control units. Warm start: A warm start is triggered by a short power failure or by the explicit command 'Maintenance\Warm-Start'. The current settings are preserved during a warm start. Cold start: A cold start can be forced if during boot-up the cold start button is pressed (above the two 1mm drillholes on the back of the control unit, on the right near the control unit socket). The control unit confirms the cold start with a beep. A cold start is also necessary if the memory content is lost due to too little battery power during an electricity failure. The control unit announces this process with the message 'crc-Failed'. In a cold start the user settings that were most recently saved are always loaded. The devices are supplied with various user settings. In particular the filters are preconfigured for the customer.

Fabriksinställning

With the command 'Factory Settings' all settings in the volatile memory are reset to the factory settings. The customer settings are stored. In the event of a system 'cold start' the customer settings are also reloaded with this command. In order for the factory settings to be selected as the standard settings after a 'cold start', they must be saved as customer settings following this command.



09903601(06)

Kundinställningarna

All settings that were changed during the current operation are reset to the customer settings. The same occurs if a cold start takes place on the control unit, or if the buffer battery is changed.



09903612(70)

Spara grundinställning

The settings in current use are saved as customer settings. This process writes data from the volatile memory into the non-volatile memory. The process only lasts a few seconds but it is very important that it is carried out completely as otherwise the control unit can be damaged. If the process is not carried out completely, it can happen that the control unit will no longer start after the next interruption to the power supply. In this event the software would have to be reinstalled. The control unit must not be switched off during the memory process. The power supply must not be interrupted. The conclusion of the memory process is signalled with a beep.



09903613(67)

Underhåll

The directory 'Maintenance' contains functions which go beyond daily use. Diagnosis, upkeep and error searches are supported through various start points. These functions should be carried out only by well trained staff.

Rapport

Ytterligare rapporter finns under 'Underhåll\Rapporter'. Här finns även funktioner som är tillgängliga för radering av data till dessa rapporter och för att sätta rapporterna till noll. T.ex. kan loggen för skotträknaren sättas till noll.

Inställningar

Printing out settings:

Utskrift

Prints out a list of the current settings that differ from the factory settings. In addition the shaft settings of the target images and the filter configurations are listed, insofar as these differ from the factory settings.



09903602(03)

Skjutning

Many settings are taken over into a program when the program is launched. Additionally a program use of additional settings that were stored when the program was being developed. The command '\Settings\Program' prints all the settings of the actively selected program.



09903610(76)

Skotträknare

Mechanical shot counters:

The optional mechanical shot counter only counts the shots on your own target. It cannot be reset. Demo shots or inserted no scores are not counted. A detailed description of the whole function can be found in the user manual under 'Mechanical shot counters'.

Software shot counters:

The software shot counter counts shots in different categories. Own shots, cross shots, missed shots, demo shots etc. are differentiated and displayed separately. The shot count report is displayed in the list window and provided a printer is connected and switched on, is printed out. The shot counters are connected to the control units. If the settings are reset to factory settings, the shot counts are also reset to zero. The same occurs when the battery has to be changed. With a normal interruption to the power supply, the values are not lost. The software shot counters can also be reset independently of the settings under 'Maintenance\Reports\Shot Counters'.

Nollställ skotträknaren

Resets the software shot counter back to zero.



09903609(79)

Ogiltigt skott

Non-allowable shots (shots during the Stop, Pause or the Show Phase and cross shots) are not only counted, they are kept in the control unit as pending and can be queried at any time. The shots are then shown with the time and if possible with the score. With a warm start or with the command 'Erase' under 'Maintenance\Invalid Shots' the report can be rejected. The shots remain in the log throughout and furthermore can be documented in a log printout.

Rensa

Rapporten för senaste korsskotten och ogiltiga skott raderas.



990560(12)

Log

Events that are of relevance for the duration of a program are filed in the memory (events memory, log). This information is needed to be able to reproduce a program after a power interruption. The CU931 investigates this data at every system start-up. If it is established that the last program to be shot was not correctly ended, then a repetition process is introduced. By means of the log past programs can also be reloaded or a copy can be printed once again. The log is stored in the volatile memory of the control unit, which is buffered with a battery. The data is protected from misinterpretation by a check sum. If the check sum is not correct at system start-up, for example due to a faulty battery, the log is initialised again. The control unit communicates this by a triple beep and a report in the list window. The log is restricted in memory size. In the event of an overload, the oldest events are overwritten by the most recent on a rolling basis. Typically more than ten programs can be stored in the log. The log can also be manually erased under 'Maintenance\Reports\Log'. The format of the printout is described in the user manual.

Rensa

The log memory is explicitly wiped. Because this means that previous programs are irretrievably erased, this command must be authorised by a further confirmation.

Bekräfta



099057(37)

Log Hex

The 'Log-Hex' is an expanded log printout which prints out all events additionally in hexadecimal form. This printout allows events to be analysed at a very detailed level. The printout is exclusively used to search for software errors.



990559(15)

Debug

With the 'Debug' reports internal conditions of the control unit can be displayed. This report permits a diagnosis of the control unit in respect of the demand, the speed of operation or the load. They serve to enable the speed and reliability of the devices to be optimised.

Rapportera förlopp

Reports the number of runs as well as the time taken by the individual processes.



Klass

Prints a report that indicates for each class how many instances are presently available, how often the designer has been contacted and how high the greatest occurrence of the class was in the past.



BIT-test

Hårdvaran kan testas med speciella kommandon. Denna test används normalt som slutkontroll vid en nyinstallation. Den kan också användas som en felbegränsning under drift.

Skotträknare

The mechanical shot counter can be made to start counting by a self test. The chosen number triggers the corresponding number of counting pulses. Thus the fastest possible meter pulse rate can be selected. The mechanical counter cannot skip any of these pulses.

1

Counting impulse(s) on the mechanical shot counters



2

Counting impulse(s) on the mechanical shot counters



3

Counting impulse(s) on the mechanical shot counters



4

Counting impulse(s) on the mechanical shot counters



5

Counting impulse(s) on the mechanical shot counters



6

Counting impulse(s) on the mechanical shot counters



7

Counting impulse(s) on the mechanical shot counters



8

Counting impulse(s) on the mechanical shot counters



9

Counting impulse(s) on the mechanical shot counters



Taveltest

The target test requests the most important status information from the LON electronic measuring system. Along with the software and hardware version, the temperature, the assembly alignment and the Target Index Code are conveyed. The running time of the enquiry indirectly provides



information on how well synchronised the equipment is with respect to time. The target test can be used to test the network cabling to the LON electronic measuring system and the functioning of the communication chips on the control unit and the LON electronic measuring system. The target test only functions if a LON electronic measuring system is connected and linked to the control unit via the correct subnet (please refer to '\Hardware\Target\Connections').

Tangentbord

The keyboard test switches the control unit into a special keyboard test mode. Every keystroke is confirmed by an entry in the list window. Hitting the Escape key permits this keyboard test to be exited.



09903505(03)

Resultattavla

The scoreboard itself has a test program available. This test program can be started from the control unit on its own scoreboard (subnet Addressing must be in agreement).



09903508(91)

Pip

The beep test issues a series of ten short beeps one after another. They must be acoustically audible from the control unit.



09903511(82)

Nollställa monitor

Med en varmstart blir kontrollenheten återstartad igen (reboot). Detta motsvarar den process som sker när kontrollenheten startar upp när den varit spänningslös för en kort period.

Bekräfta



09903600(09)

Debug

Funktioner som används endast för felsökning är samlat under '\Underhåll\Felsökning'

Debug Mode

Felsöknings moden visualiserar alla händelser i kontrollenheten. Denna visning möjliggör en exakt felsökning. I händelse av återkommande fel kan det hända att en Sius medarbetare ber dig att du skall slå på felsöknings moden för att man i efterhand skall kunna analysera och finna ett fel.

Av (Grundinställning)

Händelser som sker i kontrollenheten visas icke.



99070700(71)

På

Händelser som sker i kontrollenheten visas i listfönstret.



99070701(68)

Utskrift

Händelser som sker i kontrollenheten visas i listfönstret och på den anslutna skrivaren.



99070702(65)

Trap

Denna funktion används endast vid fel som är svåra att reproducera. I mjukvaran som är speciellt framtagen för detta, kan en triggning inprogrammeras. När felet sedan uppträder startar en speciell händelsekedja. Oftast är det felsöknings moden som igångsättes som den speciella händelsen.

Av (Grundinställning)

Kontrollenheten arbetar utan speciell feligenkänning.



99078200(75)

På
Specialbehandlingen är aktiverad.



Hårdvara

Settings that directly affect the hardware components of the control unit are stored under 'Hardware'. Some of these components are optionally available for the equipment and only have an effect when these components are running.

Resultattavla

Resultattavla

Communication to the scoreboard can be basically suppressed. Communication reduces the speed of execution of the control unit by several percent. It is therefore worthwhile to configure the SCB as 'Off' when it is not present. Communication to the SCB must be switched on before a program is loaded.

Av (Grundinställning)
Informationen sänds icke till publikskärmarna.



På
Informationen sänds till publikskärmarna



Manöverenhet

'Screen' contains several hardware settings that directly affect the control unit.

Set subnet

Sius AG devices communicate with one another via the field bus LON. Each device has its own address. One part of this address is the so-called subnet. The LON electronic measuring system and the control unit with the same subnet always belong together. Different lanes must be correspondingly differentiated in the subnet. Every LON electronic measuring system sends its own detected shots to the control unit in the same subnet in which it is itself addressed. A LON electronic measuring system with subnet 5 sends its shots to the control unit with subnet 5. By setting a subnet on a control unit only the address of the control unit is affected. A previously linked LON electronic measuring system must be reconnected after this alteration (please refer to 'Hardware\Target\Connect' and instructions for use.

Insofar as a LON electronic measuring system is located in the same subnet, the status of the control unit changes from 'Offline' to 'Stop' or 'Ready' according to whether a program is selected or not.

The subnet can be selected via the 10-er keyboard. Pressing the Enter key confirms a given value. With 'Esc' the entry can be cancelled. The F5 key allows incorrect entries to be corrected in time.

\Set subnet\1..9

1 (Grundinställning)



2



3



4



5



6



7



9907270007(40)

8



9907270008(37)

9



9907270009(34)

\Set subnet\10..19

10



9907270010(31)

11



9907270011(28)

12



9907270012(25)

13



9907270013(22)

14



9907270014(19)

15



9907270015(16)

16



9907270016(13)

17



9907270017(10)

18



9907270018(07)

19



9907270019(04)

\Set subnet\20..29

20



9907270020(01)

21



9907270021(95)

22



9907270022(92)

23



9907270023(89)

24



9907270024(86)

25



9907270025(83)

26



9907270026(80)

27



9907270027(77)

28



9907270028(74)

29



9907270029(71)

\Set subnet\30..39

30



9907270030(68)

31



9907270031(65)

32



9907270032(62)

33



9907270033(59)

34



9907270034(56)

35



9907270035(53)

36



9907270036(50)

37



9907270037(47)

38



9907270038(44)

39



9907270039(41)

\Set subnet\40..49

40



9907270040(38)

41



9907270041(35)

42



9907270042(32)

43



9907270043(29)

44



9907270044(26)

45



9907270045(23)

46



9907270046(20)

47



9907270047(17)

48



9907270048(14)

49



9907270049(11)

\Set subnet\50..59

50



9907270050(08)

51



9907270051(05)

52



9907270052(02)

53



9907270053(96)

54



9907270054(93)

55



9907270055(90)

56



9907270056(87)

57



9907270057(84)

58



9907270058(81)

59



9907270059(78)

\Set subnet\60..69

60



9907270060(75)

61



9907270061(72)

62



9907270062(69)

63



9907270063(66)

64



9907270064(63)

65



9907270065(60)

66



9907270066(57)

67



9907270067(54)

68



9907270068(51)

69



9907270069(48)

\Set subnet\70..79

70



9907270070(45)

71



9907270071(42)

72



9907270072(39)

73



9907270073(36)

74



9907270074(33)

75



9907270075(30)

76



9907270076(27)

77



9907270077(24)

78



9907270078(21)

79



9907270079(18)

\Set subnet\80..89

80



9907270080(15)

81



9907270081(12)

82



9907270082(09)

83



9907270083(06)

84



9907270084(03)

85



9907270085(97)

86



9907270086(94)

87



9907270087(91)

88



9907270088(88)

89



9907270089(85)

\Set subnet\90..99

90



9907270090(82)

91



9907270091(79)

92



9907270092(76)

93



9907270093(73)

94



9907270094(70)

95



9907270095(67)

96



9907270096(64)

97



9907270097(61)

98



9907270098(58)

99



9907270099(55)

DeltaX

Den exakta träffpunkten kan justeras horisontalt. Detta kan användas för att kompensera för onoggrannhet vid montage (ex. figurens position).

X-0.1mm

till vänster



99072800(76)

X+0.1mm

till höger



99072801(73)

X-1mm

till vänster



99072802(70)

X+1mm

till höger



99072803(67)

X-10mm

till vänster



99072804(64)

X+10mm
till höger



DeltaY

Den exakta träffpunkten kan justeras vertikalt. Detta kan användas för att kompensera för onoggrannhet vid montaget (ex. figurens position).

Y-0.1mm
nedåt



Y+0.1mm
uppåt



Y-1mm
nedåt



Y+1mm
uppåt



Y-10mm
nedåt



Y+10mm
uppåt



Meny

Tangentbordets meny kan stängas av. Detta är användbart speciellt när anläggningen skall betjänas endast med streckkodläsaren. Streckkodläsarens fördelar är att användarens behov kan sammanställas på ett pappersark.

Av
Tangentbordets menyfunktion är blockerad.
Utrustningen kan manövreras endast med streckkodläsare eller från skjutledarens PC.



På (Grundinställning)

Tangentbordets menyfunktion är inkopplad igen. Om tangentbordets meny stängs av kan den inte kopplas in igen via tangentbordet. Normalt måste inkoppling av tangentbordets funktion ske via en streckkodläsare, från skjutledarens PC eller via en kallstart.



Keystroke

För diagnosändamål kan det vara användbart om kommandon kan läsas in med hjälp av streckkodläsaren. Med hjälp av denna funktion är det möjligt att fjärrstyra en betjäningseenhet även från en central 'skjutledare' PC. Det kan ex. utföras ett demokott på alla monitorer som är anslutna. I menyn finns inte denna kommando möjlighet synlig eftersom det inte är nödvändigt.

Escape



Opt



Hjälp



Nästa fönster



9906442004(73)

Enter



9906442005(70)

Zoom



9906442006(67)

Meny



9906442007(64)

Match



9906442008(61)

Bakåt



9906442009(58)

F1



9906441001(75)

F2



9906441002(72)

F3



9906441003(69)

F4



9906441004(66)

F5



9906441005(63)

Höger



9906443001(89)

Upp



9906443002(86)

Vänster



9906443003(83)

Ned



9906443004(80)

Hem



9906443005(77)

End



9906443006(74)

Sida upp



9906443007(71)

Sida ned



9906443008(68)

Sätt in



9906443009(65)

0 (Grundinställning)



9906440000(71)

1



9906440001(68)

2



9906440002(65)

3



9906440003(62)

4



9906440004(59)

5



9906440005(56)

6



9906440006(53)

7



9906440007(50)

8



9906440008(47)

9



9906440009(44)

Set subnet



99064000(92)

Sius AG devices communicate with one another via the field bus LON. Each device has its own address. One part of this address is the so-called subnet. The LON electronic measuring system and the control unit with the same subnet always belong together. Different lanes must be correspondingly differentiated in the subnet. Every LON electronic measuring system sends its own detected shots to the control unit in the same subnet in which it is itself addressed. A LON electronic measuring system with subnet 5 sends its shots to the control unit with subnet 5.

By setting a subnet on a control unit only the address of the control unit is affected. A previously linked LON electronic measuring system must be reconnected after this alteration (please refer to 'Hardware\Target\Connect' and instructions for use.

Insofar as a LON electronic measuring system is located in the same subnet, the status of the control unit changes from 'Offline' to 'Stop' or 'Ready' according to whether a program is selected or not. The subnet can be selected via the 10-er keyboard. Pressing the Enter key confirms a given value. With 'Esc' the entry can be cancelled. The F5 key allows incorrect entries to be corrected in time.

RC92

Optionally a RC92 (shoot box) can be connected to a control unit. The RC92 is controlled by means of three buttons (Zoom, Menu and Shoot).

Match Meny

Via the Menu button an additional window can be opened on the screen. This window lists all the functions available in the Control Menu. In this way the control unit can be remotely controlled by the firer without having to leave his position.

In official ISSF contests the firer is not permitted to carry out these functions himself. It must therefore be possible to switch off the Shoot Menu.

Av

The match menu is switched off. The Match button on the RC92 has no function.



99079900(19)

På

The match menu is switched on.



99079901(16)

Kortversion

Only a reduced number of functions is available (Clear Graphics).



99079902(13)

Figur

Settings that must be communicated to the LON electronic measuring system are stored under '\Target'. These settings are also frequently dependent on the program selected and therefore can be overwritten if necessary.

Figur byte

Some detection systems are quipped with a target changer (S101, S310). Each target image has been programmed with a basic setting or a shaft. If a program with a specific target is selected, the preselected shaft is automatically activated. If the detection system is not equipped with a changing mechanism, the command is ignored. If the target image is mounted in a different shaft or if the target image on the control unit does not correspond to the physical target image, the shaft can be changed by means of the target changer commands. The target image is hereby automatically programmed for the new choice of shaft. If the same program is selected again later, the latest shaft to be selected will again be selected in any case.

A (Grundinställning)

The 'shaft' A corresponds to the fixed frame of the detection system.



09907190(06)

B

The shaft B is the alternative frame.



09907191(03)

C

With the target S101 there are two alternative frames available. The shaft C is the second alternative frame.



09907192(97)

Bandmatning

After every shot, detection systems controlling a materials handling unit (paper or rubber tape) trigger an automatic feed unit. The feed unit is measured in millimetres. Depending on the discipline and the weapon, the tape must be fed a greater or lesser distance. These distances are laid down in the target images. But every discipline can define its own actual setting values. The tape feed for a 10 metre discipline is 20 millimetres. In ISSF finals the feed distance is increased to 30 millimetres. The tape feed can be changed after a program has been selected.

\Bandmatning\Use Always

På



99077899(08)

Av (Grundinställning)



99077898(11)

0

mm



99077800(14)

1

mm



99077801(11)

2

mm



99077802(08)

3

mm



99077803(05)

4

mm



99077804(02)

5

mm



99077805(96)

10

mm



99077810(81)

20 (Grundinställning)

mm



99077820(51)

30

mm



99077830(21)

40

mm



99077840(88)

50

mm



99077850(58)

Target Lifter

Stående



09906910(70)

Liggande



09906911(67)

Knä



09906912(64)

Upp



09906916(52)

Ned



09906917(49)

Reference Calibration



09906919(43)

Anslut

This barcode switches the control unit over to a special configuration mode. The control unit waits for a service PIN message from any LON electronic measuring system. This message can be created on the LON electronic measuring system, either when the service PIN is pressed or when shooting takes place. But a shot triggers a Service PIN message only if the LON electronic measuring system was not previously configured. Every LON electronic measuring system that first reports this Service PIN message is reprogrammed by the control unit to its own subnet address. This function is used only if the LON electronic measuring system does not have its own LNR (lane number box).



99063200(67)

Light

På



9906920000(36)

Av



9906921000(43)

Brighter



9906922000(50)

Darker



9906923000(57)

Set intensity



9906924000(64)

Distance Index

0 (Grundinställning)



99081200(96)

1



99081201(93)

2



99081202(90)

3



99081203(87)

4



99081204(84)

Känslighet

The detection systems are fitted with various amplifier settings for the microphone. For most systems and weapons a low sensitivity is the correct setting. In the 25 metre rapid fire pistols with a very small recoil are used. The speed of the projectile is correspondingly small and the impact on the rubber very light. For these disciplines a high sensitivity is necessary so that the shot can always be correctly picked up. But the setting must be set to high only in these disciplines because with other firearms otherwise crosstalk onto neighbouring lines could ensue. The setting is normally correctly adjusted for the programs and must not be adjusted manually.

\Känslighet\Use Always

På



99072099(45)

Av (Grundinställning)



99072098(48)

Låg (Grundinställning)

Low sensitivity is required for most bullets.



09907200(73)

Hög

High sensitivity is needed above all for sport shooting (25m), which is shot with high recoil weapons, typically on targets S10 and S25/50



09907201(70)

Time Control Unit

Time Control Unit

Av (Grundinställning)



99080300(80)

På



99080301(77)

Duell mode

Vid discipliner där tidkontrollutrustningen används, blir olika om disciplinen är i duell-mode eller inte.

Av (Grundinställning)

När duell moden är frånslagen kan fler skott registreras under den gröna fasen.



99080400(71)

På

När duell moden är tillslagen kan endast ett skott avfyras under den gröna fasen.



99080401(68)

Graphic Printer Modell

Undefined Printer (Grundinställning)



99080500(62)

D931-SP



99080501(59)

D931



99080502(56)

iDP3240



99080503(53)

Skott sensor

The shot sensor allows cross shots and no scores to be detected. Without the shot sensor all shots are interpreted as own shots on the own target. Even a shot from a neighbouring lane onto the own target is interpreted as an own shot and included in the calculation of the results. With the shot sensor, within a certain timescale after the Shot Off signal the corresponding Shot On signal must be produced. If only a Shot Off signal is produced, the firer has not hit the target. The shot sensor can be connected to the control unit as an optional extra. At the moment when the control unit recognises the shot sensor, it switches this on automatically. If the shot sensor is removed, the control unit recognises this after a short period of time and automatically switches the shot sensor off again.

Av

On installations without a shot logoff, this setting will be switched off automatically. It is possible to switch off the shot logoff manually even though it is connected.



09907010(61)

På (Grundinställning)

The setting shot logoff ON is automatically cancelled if no shot logoff is connected.



09907011(58)

Logga in

In order that the system can adhere to the necessary rules, under certain circumstances particular information about the firer and his weapon is needed. All this information can be recorded under the section 'Registration'.

Info

Krav

With set assumptions the system requires information about weapon, position and/or firer number before a group can be loaded. As long as this information is missing the group cannot be input.

Legalisering

If a legalisation unequal to 0 is chosen, then both the practice and the firer must produce the same legalisation in their codes in order for it to be authorised. The legalisation of the firer is however only active if the firer number is requested at the same time. This command is not to be confused with the command firer legalisation, under which the legalisation of the firer can explicitly be provided. Fact: the settings '\Requirements\Legalisation' and '\Register\Legalisation' must agree or one or other must be set to 0 in order that a program can be started and shooting can take place.

0 (Grundinställning)

No legalisation is required.



99077000(86)

1

Demanded legalisation



99077001(83)

2

Demanded legalisation



99077002(80)

3

Demanded legalisation



99077003(77)

4

Demanded legalisation



99077004(74)

5

Demanded legalisation



99077005(71)

6

Demanded legalisation



99077006(68)

7

Demanded legalisation



99077007(65)

8

Demanded legalisation



99077008(62)

9

Demanded legalisation



99077009(59)

ange vapen

In order that in contests it can be determined which program was shot with which weapon, it is possible to force the setting 'Position required'. Before a program can be loaded, a weapon type must be declared.

Av (Grundinställning)

Weapon identification is optional.



99077300(59)

På

A weapon specification must be input before a program can be selected.



99077301(56)

Ange ställning

In order that in contests it can be determined which program was shot in which position, it is possible to force the setting 'Position required'. Before a program can be loaded, a position must be declared.

Av (Grundinställning)

Reporting of position is optional.



99077200(68)

På

A position report must be input before a program can be selected.



99077201(65)

Skytt ID krav

The firer number identifies the firer (see also '\Registering\Firer number'.

Av (Grundinställning)

The firer number is optional.



99077400(50)

På

A firer number must be input before a program can be selected.



99077401(47)

Legalisering

Legalisation can be loaded either individually or together with a firer number practice code. The firer must as a result input his firer number first (inclusive of legalisation) and then a program. Only when both legalisations agree, or one or other has a zero value, can the program be launched. Otherwise the screen gives the error message 'Wrong legalisation'. A firer in possession of the legalisation 0 in his practice code can shoot all programs, and a program that shows a legalisation 0 can be shot by all firers.

0 (Grundinställning)

Legalisering av skytten



99077700(23)

1

Legalisering av skytten



99077701(20)

2

Legalisering av skytten



99077702(17)

3

Legalisering av skytten



99077703(14)

4

Legalisering av skytten



99077704(11)

5

Legalisering av skytten



99077705(08)

6

Legalisering av skytten



99077706(05)

7

Legalisering av skytten



99077707(02)

8
Legalisering av skytten



9
Legalisering av skytten



Vapentyp

For the assessment of a contest, it can be important that the type of weapon used in a program that has been shot is known, for example if various rank listings are to be established for storm rifle 90 and storm rifle 57. In such a case the weapon type can be set. With the setting 'IRequirements\Weapon type' the specification of a weapon type can be insisted upon before a program can be installed. Otherwise the program would be declined with a message 'weapon type needed'. The weapon type selected is displayed on the screen and on the paper printout.

Av (Grundinställning)



Gevär



Gevär



Frigevär



Karbin



Stgw 57



Stgw 57/03



Stgw 90



Biathlon Rifle



Fripistol



Sportpistol



Rimfire Pistol








Centerfire Pistol




Grovpistol	 99076807(83)
Sportpistol FK	 99076808(80)
Ordonnans pistol	 99076809(77)
Ordonnans pistol 75	 99076810(74)
Air Rifle	 99076816(56)
Air Pistol	 99076817(53)
Air Pistol 5 Shot	 99076818(50)

Ställning

For the assessment of a contest, it can be important that the position in which shooting took place is known. In such a case the position can be input either on the menu or via a barcode. With the setting 'Requirements\Position' the specification of a position can be insisted upon before a program can be installed. The position selected is displayed on the screen and on the paper printout.

Av (Grundinställning)	 99077600(32)
Liggande	 99077601(29)
Liggande med stöd	 99077604(20)
Knä	 99077603(23)
Stående	 99077602(26)

Skytt nummer	 99063900(04)
--------------	--

The firer number identifies the firer. The firer number can also be loaded via a barcode (Sius barcode inclusive of legalisation or SSV licence card) or via the keyboard. The firer number is transferred to the central processor. From the central processor the name of the firer can be construed from the firer number. The firer number is displayed on the screen and on the printer.

Should the setting 'Firer number needed' be activated and 'Repeat allowed' be switched off, then the firer number is erased after each program. This ensures that with this configuration before every program a firer number must be introduced.

SIUS

Genvägar

1		
10	Älg 10	33, 34, 35
100	S4 D2 D2	61
101	E4 S3 S3	61, 66, 69
102	S6 D2 D2	61
103	D3D3D3	61
104	S6S8S10	61
10m	NCAA AR60	79
10X	Visa 10X	94
132	P0S10D5	63
149	D5D5D5	57
150	P5 D5 D5 D5	57
156	P5 D5 D5	57
15FP	15m fripistol	21
15FP	15m fripistol F	21
15mP	15m pistol	21
15mP	15m pistol F	21
15y	NSRA 15y	19
15yF	NSRA 15y Final	19
2		
2	IPSC Combi 2	40
20	Rifle 20	64, 74
2x30	Rifle 2*30	59, 74
3		
3*10	Gevär 3*10	64, 74
3*10	Luftgevär 3*10	64, 74
3*10	NMAR - Half Course	64, 74
3*20	50ft Rifle 3x20	74, 79
3*20	C200 3x20	74, 79
3*20	Luftgevär 3*20	74, 79
3*20	NMAR - Full Course	74, 79
3*20	Standardgevär 3*20	74, 79
3*40	50ft Rifle 3x40	74
3*40	Frigevär 3*40	74
3*40	Luftgevär 3*40	74
30	Rifle 30	64
3xFi	3 Positions Final	59, 79
3xFi	50Ft 3Position Final	59, 79
5		
5	Älg 5-5-4-3	33, 34, 35
50ft	50ft Rifle 3x20	74, 79
5K20	Femkamp 20	54
5K30	Femkamp 3*10	54
5Kam	Femkamp	53
6		
60	C200 60	74
60	Frigevär 60	74
60	Gevär 60	74
600	Scale Factor (600)	110
9		
92	P0S10	60
93	P0 D5 D5	60
A		
A1	MG Ziel A1	29
A10	Precision	5, 28, 39, 41, 78
A101	A10 100m	23
A102	A10 200m	23
A103	A10 300m	23
A10m	Pistol A 10m	24, 75
A10m	Rifle A 10m vertical	24, 75
A2	MG Ziel A2	29
A20m	Rifle A 20m vertical	25, 77
A3	MG Ziel A3	30
A4	MG Ziel A4	30
A5	MG Ziel A5	30
A-5m	Pistol A 5m	23, 75
A6	MG Ziel A6	30
A7	MG Ziel A7	30
A8	MG Ziel A8	30
Adm	Administratör	115
Akti	MTP	106
Akti	Resultattavla	106
Ansl	Anslut	135
AnvG	Användar grupp	114
AP30	Air Pistol 30	54
AP30	Standard Pistol 30	54
AP5	Air Pistol 5 Shot	141
APis	Snabbpistol	54, 56, 79
AR20	Air Rifle 20	54
ATE	Target Lifter	88, 134
AuRe	Automatisk nollställning	110
AUT	Austria	23, 75
AutE	Automateld	5, 6
AutE	Snabb	5, 6

SIUS

Genvägar

AutS	Automatisk uppstart	110
Av	0	98, 101, 132, 134, 135, 138, 139
Avan	Avancerad	114
Avbr	Avbryt	87
Avlä	Avlägsna	118

Ä

Älg	Älg vänster/höger	60, 78
Älg	Mini Älg	60, 78

B

B1	Bersaglio 1	22
B1	MG Ziel B1	22
B10m	Pistol B 10m	24, 76
B10m	Rifle B 10m horizontal	24, 76
B2	Bersaglio 2	22
B2	MG Ziel B2	22
B20m	Rifle B 20m horizontal	26, 77
B3	Bersaglio 9	22
B3	MG Ziel B3	22
B4	MG Ziel B4	31
B5	MG Ziel B5	31
B-5m	Pistol B 5m	24, 75
B6	MG Ziel B6	31
B7	MG Ziel B7	31
B8	MG Ziel B8	32
Båda	På båda	105
BäsS	Bästa skott	99
Bekr	Bekräfta	120, 122
BerS	Beräkna serie	87
BFrn	Björn front	36
Bhög	Björn höger	36
BIT	BIT-test	121
BO10	Rifle B 10m ellipse	26, 77
BO20	Rifle B 20m ellipse	26, 77
Brcd	Redigera streckkod	89
Bvän	Björn vänster	36
BytF	Figur byte	133

C

C1	MG Ziel C1	32
C15m	Pistol C 15m	24
C15m	Rifle C 15m	24
C2	MG Ziel C2	32
C3	MG Ziel C3	32

C30m	Rifle C 30m	26, 77
C4	MG Ziel C4	32
C5	MG Ziel C5	32
C6	MG Ziel C6	33
C7	MG Ziel C7	33
C-7m	Pistol C 7m	24
C8	MG Ziel C8	33
CA11	Pistol C All	25
CA11	Rifle C All	25
CFP	Centerfire Pistol	140
CFP	Grovpistol	140
Cirk	Cirkel	93, 95
Cmpl	Komplett	64
ConB	Convert both sighters	87
ConL	Convert last sighting shot	87
CroA	Croatian AR Target	4

D

D100	DFS100	15, 48, 84
D10m	Pistol D 10m	24, 76
D15m	DFS 15m	14, 48, 83
D200	DFS 200	15, 48, 84
D300	DFS 300	15, 48, 84
D40m	Rifle D 40m	26
D-5m	Pistol D 5m	24, 76
DA11	Rifle D All	27
DAN	Dansk	108
Dans	Danmark	19, 58, 64
Dans	Final	19, 58, 64
DDSR	15m riffel 1984	20
DDSR	15m riffel 1984 F	20
Debg	Debug	97, 121, 122
Debg	Debug Mode	97, 121, 122
Defe	Deferred Shots	94
DeIS	Delsumma	85, 100, 103
DeMo	Demonstration Mode	118
Dist	Distance Index	135
Dist	Distans	135
Dold	Dolda skott	66, 68, 70, 86
DSkR	15m riffel DskyU 1982	21
DSkR	15m riffel DskyU 1982 F	21
D-SP	D931-SP	136
Dubb	Dubbel	35, 73, 99
Duel	Duell mode	136

E

SIUS

Genvägar

E10	P2S10	68	GER	Deutsch	107
E2	Nachdoppel	62, 63	Gev	Gevär	6, 7, 11, 25, 28, 51, 60, 76, 81, 83, 113, 140
E20m	Pistol E 20m	25	Gev	Luftgevär 10	6, 7, 11, 25, 28, 51, 60, 76, 81, 83, 113, 140
E6E4	P2S6S4	68	GKal	Grovkaliber	9, 58
EAll	Pistol E All	25	GPis	Grovpistol	56, 79
ENG	English	107	GrGr	Gross Gross	28
ESP	Español	108	Gris	Gris 2	36
Euro	Europeisk	109	Gris	Gris 5	36
EurS	Europeisk+sekunder	109	Gris	Gris 5 höger	36

F

Fabl	Fabriksinställning	119	Gris	Vildsvin höger SWE	36
FB	Full Bore	42, 75	Gris	Vildsvin v/h SWE	36
FelF	Felfunktion	86	Gris	Vildsvin vänster SWE	36
Fig	Figur	133	GrKl	Gross Klein	28
Fig	Figurer	133	GrLi	Gross links	27
Fig	Taveltest	133	GrRe	Gross rechts	28
Fig1	1/1 figur	41, 78	Grul	Grundinställning	96, 97, 110
Fig2	1/2 figur	41, 78	Grul	Kundinställningarna	96, 97, 110
Fig3	1/3 figur	42, 78	Grup	Grupp	102
Fig8	1/8 figur	42, 78			
FigM	Info tavelmatning	105			
FigN	Visa figurnamn	105			
Filt	Filter	111			
Fina	Final	3, 7, 19, 74, 80, 81, 103	H-	Timme-	108
Fina	Junior 4P Final	3, 7, 19, 74, 80, 81, 103	H+	Timme+	108
FinK	Finkaliber	8, 49, 58	hGms	Gems Hubertus	39
FinX	Fin kyss	93, 95	Höge	Pistolman from right	40
FldA	Fält A	65	Högr	Höger	34, 99, 110, 131
FldB	Fält B	65	HRåd	Rådjur Hubertus	39
FldD	Fält C	65	HrdV	Hårdvara	123
Form	Datumformat	109	Hwal	Hans Waldmann Schiessen	73
Fot	Sidfot	102			
FPis	Sportpistol FK	141			
FRA	Francais	108	I		
FRes	Final reserverad	74	IDP3	iDP3240	137
FriS	återställa fria serier	109	Indi	Indikera	105
FriS	Fria serier	109	Inf0	Införa skott '0'	87
FriS	Frigevär	109	InsK	Kontroll inställningar	119
Frst	Grundomgång	74	Inst	Inställningar	92, 119
Funk	Funktion	115	Inst	Ställ in timer	92, 119
FuTn	Funktions tangenter	103	Inve	Invertera	92, 94, 96
Fyll	Fylla serier	86	ISSF	(Ringar)ISSF Vildsvin	60
			ISSF	ISSF Vildsvin	60
			ITA	Italiano	108
			ITA	Italy	108

G

SIUS

Genvägar

J

Jakt	Belgium	16, 112
JuTi	Justera tid	108

K

Kal	Kaliber	93, 95, 105, 117
Kal	Reference Calibration	93, 95, 105, 117
Kalv	Älgkalv	34, 35
Käns	Känslighet	136
Karb	Karbin	140
Katg	Kategori	112
KGeS	Radera tavlan efter skott	98
KI 1	A ARE V65 V73 1 AG3	84
KI 1	B ARE V65 V73 1 AG3	84
KI 2	A KI J 2 V55 Åpen	84
KI 2	B KI J 2 V55 Åpen	84
KI34	A KI 3 4 5	84
KI34	B KI 3 4 5	84
Klas	Klass	121
Klas	Klassisk	121
KIGr	Klein Gross	28
KIKI	Klein Klein	28
KILi	Klein links	27
KIRe	Klein rechts	27
Knbn	Knabenschiessen	73
Kolm	Kolumnkonfiguration	99
Komb	Kombinerad	66, 68, 71
KonM	Control Mode	118
Kont	Kontrollera	85
KorS	Kors skott	98
Kort	Kortversion	109, 133
Krys	Kryss	93, 95

L

LadO	Föreg. serie	90
Layo	Layout	103
LCD	På LCD	104
Lega	Legalisering	138, 139
LfLw	Large font in Listwindow	104
LG30	Luftgevär 30	54
LG40	Luftgevär 40	53, 79, 80
LG60	Luftgevär 60	53, 79, 80
LGev	Air Rifle	141
LGev	Luftgevär	141
LGev	Luftgevär 10	4, 55

Ligg	Liggande	134, 141
LigS	Liggande med stöd	141
LM	Lag mästerskap	65
LogH	Log Hex	120
Logn	Logga in	115, 138
Loka	Lokal	118
LP20	Air Pistol 20	54
LP40	Luftpistol 40	53, 79
LP40	Standard Pistol 40	53, 79
LP60	Luftpistol 60	53, 79
LP60	Standard Pistol 60	53, 79
LPis	Air Pistol	141
LPis	Airpistol 10 Rim	141
LPis	Luftpistol	141
LPis	Luftpistol 10	141
LSW	Last Shot Window	94
Luft	Luftvapen	116

M

M1	2x1/3 figur	41, 78
M2	1/1+1/3 figur	41, 78
M3	1/8+1/2 figur	41, 78
M90	50m riffel M 90	20
M90	50m riffel M 90 F	20
M96	15m luftriffel M 96/G	20
M96	15m luftriffel M 96/G F	20
MaFr	Line feed	102
Mån-	Månad-	108
Mån+	Månad+	108
Mäst	Svenskt mästerskap	74
Matc	Match	85, 131
Matn	Bandmatning	133
MCRW	Stopp vänster	103
Medd	Meddelande	104
MedP	Med provskott	66, 67, 68, 69, 71
Meny	Match Meny	133
Min-	Minut-	109
Min+	Minut+	109
Mitt	Mellan omgång	74
Moni	Manöverenhet	103, 123
Moni	På monitor	103, 123
Morg	Morgarten	10, 63, 73

N

N15m	NSF 15m	14, 48
NäsP	Nästa skottvalör	89

SIUS

Genvägar

NäsS	Nästa decimalskott	89	Pist	Luftpistol 10	4, 55
NoIM	Nollställa monitor	122	Pist	Pistol	140
Nome	Name	102	Prec	Precision	5, 28, 39, 41, 78
NOR	Norge	14, 43, 83	Pres	Presentation	92
NOR	Norsk	14, 43, 83	Proc	Rapportera förlopp	121
Nr	Nummer	93, 95	Prog	Program	53, 116
Nr	SkottNr Valör	93, 95	Prog	Svenskt skjutprogram	53, 116
NrIn	Print number of Innertens	100	PrOT	Print Overtime	100
NrOI	Number of Instancies diff		Prot	Skriv ut skjutprotokoll	99
NSve	Nya Svenska	15	Prov	Provskott	54, 85, 100
NTC4	NTTC4	17	PtrE	Enkel	110
NTC5	NTTC5	17	PtrE	Enkelskott	110

O

Ogil	Ogiltigt skott	98
OgiS		98
Ohne	P0 ohne Druck	55, 56, 57, 61, 62, 63, 65, 67, 69, 70
Oly1	Oly100	16
Oly2	Oly200	16
OP A	OP A5 Dela 1	65
OP B	OP B4 Dela 2	65
OP P	OP A5 Prov	65
OP P	OP B4 Prov	65
OpnS	Opening shooting	68, 73
Or75	Ordonnans pistol 75	141
OrdP	Ordonnans pistol	141
Otil	Icke tillgänglig	87

Ö

Öfns	Övningsfönster	104
Övn	Omgång	86, 102
ÖvnL	Utbildnings kontroll	118
Övr	Övrigt	4, 17, 36, 46, 54, 58, 64, 72, 74, 80, 87, 103, 109, 111, 112, 113, 115

P

P60	Pistol 60	59, 79
PA00	PA100	8, 9, 63
Para	Krav	138
Para	Parametrar	138
PB00	PB100	9, 10
PffW	Pfäffiker vinterprogram	73
Pist	Fripistol	140

R

R BC	Activate remote barcode	118
Råbo	Rörligt Råbock	60
Rade	Rensa	110, 120
RadL	Radera lista	87
RadT	Radera tavlan	87
Rapp	Rapport	90, 119
Rapp	Visa skotträknaren	90, 119
Rep	Möjliggöra Repetering	109
Rep	Repetera	109
Res	Reserverad	74
ResT	Resultattavla	123
Resu	Resultat	86
Resu	Resultattavla	123
Resu	Simulera resultattavla	86
RF3x	Rapid Fire 3x20	64
RFPM	Military Rapid Fire Men	56
RFPW	Military Rapid Fire	56
Rifl	Rifle 30 (15+15)	61
Ring	Råbock Ringar	37, 60
Rmov	Ta bort timer	88
Rör	Rörligt mål	3, 11, 53, 59, 117
Rset	Nollställ skotträknaren	120
Rset	Nollställ timer	120
Rset	Reset	120
RsNr	Nollställa skottnummer	102
Rubr	Sidhuvud	102
Rus	Russian	108
RUS4	Russian No. 04	6, 58

S

S3	10-delt figurskive (S3)	20, 21
S3 t		20, 21

SIUS

Genvägar

Visa	Visa meddelanden	104
VisF	Visa format	97
Voeg	Vögelinsegg	73

X

X	DeltaX	129
X+01	X+0.1mm	129
X+1	X+1mm	129
X+10	X+10mm	130
X-01	X-0.1mm	129
X-1	X-1mm	129
X-10	X-10mm	129
XY	Spridning	107

Y

Y	DeltaY	130
Y+01	Y+0.1mm	130
Y+1	Y+1mm	130
Y+10	Y+10mm	130
Y-01	Y-0.1mm	130
Y-1	Y-1mm	130
Y-10	Y-10mm	130

Z

Zi30	Zimmerstutzen 30	54
------	------------------	----